


MANUAL INSTRUCTIONS


Rattan Wicker Couch




✉ (24/7): service@kmcglobe-us.com

☎ (USA) +1 213-816-4788


PARTS




N X 1




M X 1




O X 1




V X 1




D X 2




P X 2




E X 2




R X 1



Q X 1



S X 4




T X 1




U X 4

PARTS



I X 12



L X 1

HARDWARE



M6x25mm

F X 24



M6x30mm

G X 28



H X 28



K X 1



M6x35mm

W X 2

1



G X 2




H X 2





W X 1


W




N



M



N




2




G X 8





H X 8




O



3



4



5




G X 2



H X 2



W X 1





6




G X 8




H X 8





7





8





9





10




11



12



13



14

