




### Version 1.2























4/41

# Side drawers





# Middledrawer






6 / 41







8 / 41




9 / 41




11/41





12/41







14/41







16/41












20/41




21/41




22/41




23/41







into the interior of the dressing table



27/41













While holding 5 board in place, you need another person to hold it in place by hand





31/41













36/41




37/41



38/41

# 52 Instructions for using Smart Mirror



### 1. Three-color controllable lighting

Touch the HOME button to control the light switch and light color adjustment.

When the light is on, long press the HOME button to control the light brightness (the light brightness can be remembered).

#### 2. Time display adjustment mode


When the light strip is off, long press the HOME button to enter the time SET MODE, and the clock bit flashes.

Please touch the HOME button to adjust the clock.

Long press the HOME button again, the minute digit flashes.

Please touch the HOME button to adjust the minute.

Finally, long press the HOME button again to exit SET MODE.



41/41