


# ASSEMBLY INSTRUCTIONS

---

## HALF HEIGHT DOOR KIT



**NEED HELP?**  
Call 1-800-950-4782  
[www.bushbusinessfurniture.com](http://www.bushbusinessfurniture.com)

Lot Code #



## WARNING



Do not move unit when loaded.  
Doing so could cause instability,  
product collapse, tip over, and/or  
serious injury.

---

No mueva la unidad cuando esté  
cargada. Hacerlo puede causar  
inestabilidad, que el producto se  
derrumbe, que se la caiga encima y/o  
heridas (golpes) serias.

---

Ne pas déplacer l'unité lorsqu'elle est  
chargée. Faire ainsi peut causer  
l'instabilité, l'effondrement ou le  
renversement du meuble et/ou des  
endommagements sérieux.



WC12911

A [ 2 ] W127986

WC24411

A [ 2 ] W96137

WC36711

A [ 2 ] W127988

WC48511

A [ 2 ] W93082

WC60311

A [ 2 ] W127990

WC67511

A [ 2 ] W151990

WC72411

A [ 2 ] W96965


SCB236WH

A [ 2 ] W184380


SCB236SG

A [ 2 ] W184426


Fasteners are shown in actual size.  
 los fijadores son demostrados en su tamaño actual.  
 les attaches sont montrées dans l'échelle grandeur.

H28917  [ 8 ]  
 #6 x 1/2"


H126359




H77351





H29206





H126364





## WC24411, WC48511, WC67511, WC72411




## WC12911, WC36711, WC60311



## SCB236WH, SCB236SG






Left mounting option  
Opción para montura izquierda  
Option gauche de montage


Right mounting option  
Opción para montura derecha  
Option droite de montage

Go to Step 4.  
Proceda al paso 4.  
Allez à l'étape 4.







WC12914  
WC24414  
WC36714  
WC48514  
WC60314  
WC67514  
WC72414  
SCB136WH  
SCB136SG



Go to Step 6.  
Proceda al paso 6.  
Allez à l'étape 6.






WC24411, WC48511, WC60311, WC72411




WC12911, WC36711, WC60311



SCB236WH, SCB236SG




H126364




[ 2 ]

Mounting Plate





Left mounting option  
Opción para montura izquierda  
Option gauche de montage





Or  
O  
Ou

Right mounting option  
Opción para montura derecha  
Option droite de montage

Left mounting option  
Opción para montura izquierda  
Option gauche de montage




A






Door adjustments  
Ajustes de la puerta  
Réglages de la porte




**HOW TO**  
**Adjust Door**  
**Hinges**





WC24411, WC48511, WC60311, WC72411



WC12911, WC36711, WC60311



SCB236WH, SCB236WH



H126364



[ 4 ]

Mounting Plate

