






Outdoor Wicker Rectangular Side Table




PART LIST

A	B	C
		
Wicker Top 1PC	Side Panel 2PCS	End Panel 2PCS

HARDWARE LIST


#1	#2	#3	#4
			
M6*30mm	M6mm	M6mm	M6mm
Bolt 12PCS	Washer 12PCS	Allen Key 1PC	Adjustable Leveler 4PCS

EXTRA HARDWARE LIST

#1	#2	#4
		
M6*30mm	M6mm	M6mm
Bolt 3PCS	Washer 3PCS	Adjustable Leveler 1PC


Step 1. Lay wicker top (part #A) on a flat surface with underside facing up. Attach one side panel (part #B) to the wicker top (part #A) using bolts (part #1), washers (part #2) and allen key (part #3). Attach one end panel (part #C) to the assembled parts (part #A & B) using bolts (part #1), washers (part #2) and allen key (part #3).

NOTE: Please do not fully tighten bolts until unit is fully assembled.




Step 2. Attach remaining side panel (part #B) to the assembled parts (part #A, B & C) using bolts (part #1), washers (part #2) and allen key (part #3). Attach remaining end panel (part #C) to the assembled parts (part #A, Bx2 & C) using bolts (part #1), washers (part #2) and allen key (part #3).

NOTE: Please fully tighten all bolts at this time.



Step 3. Screw the adjustable levelers (part #4) into the bottom of the table. Adjust as needed to desired position.



#4  x4

Step 4. Carefully turn the table upright.

