

WARRANTY

We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.


**Are you having difficulty
with assembly? Missing parts?**

**Please send email with your order No.
to our website.**

**For return, Please check the return policy with
the retailer or MarketPlace you bought from.**

Appreciated your purchasing from us.

Pop up your life by our furniture piece!



TRIPLE SOFA UNIT

NOTE:

This brochure contains IMPORTANT safty info. Please read and keep for future reference.

MAINTAINANCE ANDWARNING

- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish.Do not use detergents,Solvents,abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight,material will possibly padeover time.
- Do not useon sitedryCleaning machine.
- Childrenshouldnotclimborjumponthe furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- To obtain the longest lifespan of your outdoor products,avoid exposure to rain or snow,and direct sunshine for long time.Whenever possible cover the product and/or place under patio or awnings.
- Not for commercial use, For residential use only.



Weight Limitation


500LBS

Assembly Instruction

TRIPLE SOFA UNIT

A	Handrail Bag	2PCS	F	Left Handrail	1PC	5	Allen key M6	1PC
	Headrest			Right Handrail			Shim	
B		2PCS	G		1PC	6	M6	4PCS
C	Rely on backpack	1PC	1	Front Leg	2PCS	7	Spare screw M6*50mm	1PC
	Backrest			Plastic gasket			Spare Shim M6	
D		1PC	2		5PCS	8		1PC
E	Seat	1PC	3	Back Leg	2PCS	9	Spare Plastic gasket	1PC
				Screw M6*50mm			Middle Leg	
			4		4PCS	10		1PC


Assembly Steps




This Sofa has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Sofa parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.
Note: It is recommended that you have an adult partner to assist during the entire assembly process.

Assembly Preparation


Before
Beginning
Assembly



STEP 1 Align and insert the metal bracket of seat (E) downwards into the metal bracket of arm (F) and (G) till the end. Make sure they are connected tightly and secure.




STEP 2 Align the metal cracket on the backrest(D) to the seat(E), push downwards to tighten and be secure.




⚠ 扶手.坐框.靠背齐平后再锁螺杆




STEP 3 Align the hole of seat(E) to the screw hole of backrest(D), screw in sequence hardware ④⑥ with Allen Key ⑤ till fully tighten



STEP 4 Screw in the legs. make sure front legs & middle leg and rear legs in right position.



STEP 5 Insert the headrest(B) into the hole of backrest. make sure they are securely.



Assembly completed.

Care & Maintenance

- Furniture may scratch floors. We recommend using furniture pads to protect your floors.
- Do not put hot items directly on furniture surface.
- Do not clean furniture with harsh cleansers or polish.
- Do not place furniture under direct sunlight.
- Do not place furniture near heating or cooling vents.
- Do not write on furniture without a padded barrier to protect the surface.
- Do not place furniture outside . For indoor use only.
- Not for commercial use . For residential use only.
- Stains may be removed with mild soap solution and damp cloth.
- Children should not climb or jump on the furniture.
- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

WARNING:

- BE SURE TO CHECK ALL PACKING MATERIAL CAREFULLY FOR SMALL PARTS, WHICH MAY HAVE COME LOOSE INSIDE THE CARTON DURING SHIPMENT
- DO NOT STAND ON THE SOFA
- THE SOFA WAS DESIGNED FOR THREE PERSON USE ONLY.
- DO NOT USE THE SOFA UNLESS ALL THE BOLTS AND SCREWS ARE FIRMLY TIGHTENED
- ACCORDING TO YOUR OWN USAGE, CHECK THE CONDITION OF THE SCREWS REGULARLY, AND LOCK THEM IN TIME IF THEY ARE FOUND TO BE LOOSE.
- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USING THIS PRODUCT IMMEDIATELY UNTIL REPAIRS ARE MADE USING FACTORY AUTHORISED PARTS
- FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY