






ASSEMBLY INSTRUCTIONS

Roswell 15.75”D Swag

1. Carefully remove all parts from the carton and place them on a clean surface. Please refer to the list of included items inside the carton.
2. Secure 3 pinch swag hooks (A) to ceiling and wall based on placement with the anchor screws provided.
   a. To install each swag hook (A), drill a pilot hole for the anchor and then hammer in the anchor.
   b. Secure the backplate into the anchor with a screw.
   c. Loosen both setscrews on the hook body with the allen wrench provided.
   d. Thread hook body onto backplate.
   e. Tighten top setscrew to secure the hook to the backplate.
3. Position the cord of the swag assembly (B) into the pinch swag hooks (A) where desired. Tighten lower set screws of the swag hooks (A) to secure cord.
4. Attach the shade support bracket (C) to the socket of the flush mount assembly (B) and secure with socket ring (D).
5. Insert the light bulb (E) into the socket.
6. Pull the top (larger opening) of the shade (F) over the shade support bracket (C) from the bottom and secure the loops of the shade opening on the top hooks. The bottom opening of the shade (F) will automatically catch on the bottom of the bracket (C) to expand the shade.
7. Plug into a surge protected 120v outlet and enjoy the beautiful light!





ITEMS INCLUDED / ARTÍCULOS INCLUIDOS					
A  PINCH SWAG HOOK/ GANCHO DE PELLIZCO PARA CORTINAS	B  SWAG ASSEMBLY/ MONTAJE DE SWAG	C  SHADE SUPPORT BRACKET/ SOPORTE PARA CORTINA	D  SOCKET RING/ ANILLO DE ENCHUFE	E  LIGHT BULB/ BOMBILLA	F  SHADE/ PANTALLA

IMPORTANT SAFETY INSTRUCTIONS

This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

INSTRUCCIONES DE SEGURIDAD IMPORTANTES

Esta lámpara tiene un enchufe polarizado (una de las clavijas es más ancha que la otra) como medida de seguridad para reducir el riesgo de descarga eléctrica. Este enchufe solo encaja en una toma de corriente polarizada de una sola manera. Si el enchufe no entra completamente en la toma, gírelo. Si aun así no encaja, contacte con un electricista cualificado. No lo utilice nunca con un cable de extensión a menos que el enchufe pueda insertarse completamente. No modifique el enchufe.