"STARGAZER" INFLATABLE TENT USER MANUAL


WE RECOMMEND...

1-2 People

Rubber Mallet

Level Area

Equipped air pump



PACKING DETAILS

Check package contents and ensure you have all components listed below.



Storage bag x 1



Small clips x 15




Stakes x 14



String Light x 1



Air Pump x 1



Inflatable Tent x 1

PLEASE NOTE


- **TPU WINDOWS**
  - Wrinkles are normal upon first opening. Don't worry—they will smooth out over time.
- **WATCH AIR PRESSURE (IMPORTANT)**
  - Air expands in heat and contracts in cold.
  - Hot Days: If beams feel too hard, release some air to prevent bursting.
  - Cold Nights: Beams may soften naturally; top off with the pump if needed.

How to Set Up Your Tent?

Step 1

PREPARE THE SITE

- Remove sharp objects (rocks, sticks) from the ground before pitching to prevent injury and floor damage.
- Spread the tent flat on the ground. Pull the floor taut and stake out the four corners.




Step 2

CONNECT THE PUMP

- Find the Valve: See the large inflation valve at the bottom right of the door (Fig. A).
- Use Either Nozzle: The pump has 2 nozzles. Both work with this valve (Fig. B).
- Attach the pump and start to inflate


SETUP TIP:Have a helper gently lift the roof while inflating. This helps the tent take shape faster.



Step 3

SECURE THE TENT WITH THE GUY ROPES

- Inflate until the tent is fully erect.
- Pull all guy lines and webbing loops taut, then secure with stakes.




Stove Jack Setup & Safety

SETUP (Do this first):

- Slit: On first use, cut a tight "X" in the marked center.
- Flap: ALWAYS roll it up and secure it away from the pipe when stove is on.

DANGER: FIRE & CARBON MONOXIDE HAZARD

- HOT PIPE MUST NEVER TOUCH FABRIC.
- YOU MUST VENTILATE & USE A CO DETECTOR.
- Use only with certified, vented stoves.



CARE & MAINTENANCE

1. CLEANING

- Spot Clean Only: Wipe with a soft cloth and cool water.
- Remove Stains Promptly: Clean bird droppings and tree sap immediately to prevent permanent damage to the fabric coating.

2. DRYING (CRITICAL)

- 100% Dry: Ensure the entire tent is completely dry before storing to prevent mold.
- Wet Pack Remedy: If forced to pack wet, unpack within 24 hours and air dry in the shade.
- Avoid Direct Sun: Prolonged UV exposure will degrade the fabric and air beams. Always dry in a shaded area.

3. STORAGE

- Deflate & Fold: Expel all air. Fold along the direction of the air beams—do not twist or force sharp creases.
- Environment: Store in a cool, dry place. DO NOT stack heavy objects on top of the bag.
- Maintenance: For long-term storage, unpack every 6 months to let the fabric breathe.

4. REPAIR

- Minor punctures in the air beams can be fixed using a TPU repair patch (sold separately).