



Smokey Fire Pit

DESIGNED IN 2018

ASSEMBLY NOTES | REV 01




ONLY YOU CAN HELP PREVENT UGLY FIRE PITS.

Smokey is equal parts minimal steel sculpture, fire containment and entertainment facilitator. Do not use inside. No, really, don't do it.

NEED A HAND?


Contact us at service@bludot.com or **844.425.8368** for assistance.

Parts & Hardware



QTY 3

Foot



QTY 1


Fire Pit

Step 01

ATTACHING THE FEET.

Place the fire pit face down on a soft surface. Thread the adjustable feet onto the fire pit as shown.

Note: This product is intended for outdoor use only. Place the fire pit on a level non-combustive surface. Check with your local fire department for rules and regulations concerning outdoor fire pit use.



Safety and Compliance Information

- This product is intended for outdoor use only. Do not use indoors or in enclosed spaces due to the hazard of carbon monoxide fumes and fire. Lack of ventilation may cause property damage and/or death.
- This product is to be used a minimum of 20 ft. from building walls, overhangs, or near any unprotected combustible constructions. Avoid using near or under overhanging trees and shrubs.
- Do not use this product on combustible surfaces such as: wood or engineered decks, dry leaves, or dry grass.
- This product is for ADULT use only.
- Always use in accordance with all applicable local, state, and national codes. Contact your local fire department for details on outdoor burning.
- The use of alcohol, prescription, or non-prescription drugs may impair the consumer's ability to safely operate this outdoor product.
- Do not use this product near automobiles, recreational vehicles, or combustible furniture.
- Do not leave this product unattended at any time during use, especially around children or pets.
- Never use flammable accelerants, such as: gasoline, alcohol, or paint thinners to start a fire.
- This product is intended to burn dry, untreated solidwood. Never overfill or use the fire pit to burn leaves or trash.
- The surfaces of the fire pit can get very hot. Caution must be used when handling this product after use. Never move the fire pit when in use or immediately after use.
- Completely extinguish any active fires or embers before leaving.

▲ PROPOSITION 65 WARNING

Combustion byproducts produced when using this product can expose you to chemicals including black carbon, which is known to the State of California to cause cancer, and carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to: www.P65Warnings.ca.gov/product.

Additional Information

NOTE

For longer product life, empty the fire pit before each use. Do not use abrasive cleaners on painted metal as it may affect the surface finish.

CLEAN

Clean with a slightly damp, soft cloth. To remove dirt, use a quality cleaner formulated for painted metal. Wipe completely dry with a soft cloth.

MAINTAIN

Cover during periods of non-use. Store indoors during winter months.

