


# Assembly Instructions

Warnings: You must read this before you proceed

## Wooden Frame









**CAUTION : This frame is NOT a TOY.**  
**Keep your child / children at bay in the process of assembly.**

### Parts List


Label	Picture	Description	QTY
M1		Left Arch leg	2
M2		Right Arch leg	2
N		Arch connect	1
O		Arch stop	2
P		Straight stop	2

# Hardware

Label	Picture	Description	QTY
E		Bolt	4
F		Bolt	4
G		Nut	10
D		Eye Bolt	2
H		Washer	20
W		Bucket Wrench	2

## Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

# Assembly Steps

## Step 1




Attach Left Arch leg(M1), Arch stop(O), Right Arch leg(M2) together using Hardware(G,H,F) with Bucket Wrench(W) .

Repeat this step to assemble another piece of Left Arch leg(M1), Arch stop(O), Right Arch leg(M2) up.

Do not over tighten the bolts.


## Step 2



Attach Arch connect(N) between Arch leg(M1,M2),using hardware(H,F,G) with Bucket Wrench(W)


Do not over tighten the bolts.

### **Step 3**



Attach the tail end of Arch stop (O) to the Arch connect(N) using Eye bolt(D) with hardware (H,G) and Bucket Wrench(W) .  
Do not over tighten the bolts.



















### **Step 4**



Attach Straight stop(P) to Arch leg(M1 , M2) using hardware (G,H,E) with Bucket Wrench(W) .  
Then tighten all the Bolts .  
And this frame is ready for hanging chair seat.



## Care & Maintenance

-   • Do not put hot items directly on furniture surface
  -   • Do not clean furniture with harsh cleansers or polish.
  -   • To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
  -   • Children should not climb or jump on the furniture.
  -   • Do not write on furniture without a padded barrier to protect the surface.
  -   • To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
  -   • Not for commercial use. For residential use only .
  -   • Stains may be removed with mild soap solution and damp cloth.
- 
-   • Dust and pick-up spills using a clean, non-colored, lint-free cloth .

### What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

### Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning.

### Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

### Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

