

# AMAX LED FLUSH MOUNT

## SAFETY INSTRUCTIONS

1. Before wiring to power supply, turn off electricity at fuse or circuit breaker.
2. Installation and servicing should be performed by qualified personnel only.
3. Failure to follow the above safety instructions can lead to serious injury, fire and damage to the LED fixture.
4. This fixture will only work with 120VAC input power supply. Any other power supply may damage or destroy it.
5. Suitable for damp locations.
6. Products damaged due to incorrect installation will not be covered by warranty.

**WARNING** Risk of electric shock. Turn off the electrical supply before installation.

## INSTALLATION INSTRUCTIONS

1. Remove the metal ring and plastic shade from ceiling pan by unscrewing the cap nuts.
2. Attach the two mounting screws to the outlet box, and screw them in 2 to 3 turns.
3. Pull out the source wires from the outlet box. Make wire connections using wire connectors as follows:
  - Connect the hot wire (black insulation) from the fixture to the black wire from the power source.
  - Connect the neutral wire (white insulation) from the fixture to the white wire from the power source.
  - Attach the fixture ground wire (bare wire) to the outlet box. Then connect it to the house ground wire with the wire connector.Carefully put the wires back into the outlet box.
4. Attach the ceiling pan to the outlet box by inserting two mounting screw heads into the key holes, and rotate the ceiling pan until it is locked in place, then secure the mounting screws tightly.
5. Select the color temperature you need, and set the Toggle switch to the corresponding color temperature position.
6. Lay the plastic shade into metal ring, attach them up to the ceiling pan by inserting the threaded studs, then secure them with cap nuts.

Customer service: 888-945-5221.

Do not return to the store.

