

## Changer Assembly:

1. Take out the changer and 4 tubes (pic 1)



Put the 2 long tubes on the back side of the changer (pis be sure that the hole direction is correct ) ( pic 2).



3. Put the tube with the plastic hook to connect the long tubes on one side, then the other side.

Attention: The plastic hooks face the forward direction (indicated by arrow). (pic 3.4.5).



8

4. Then push the fabric through the plastic hook (pic 6, 7) and then use the Velcro to secure (pic 8). Then the changer is assembled (pic 9 10).



Music Center toy bar Assembly:



2. Connect part 1, 2 and 3 (pic 2, 3.4.5)









Connect part 4.5 .6 7(pic 6.7)

















Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: lpswich

- \* Reward Points
- \* Exclusive Customer Service
- \* Personalized Recommendations
- \* Permanent Shopping Cart
- \* Order History



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

