


# ASSEMBLY INSTRUCTIONS

---



## TOOLS REQUIRED



Screwdriver  
( Not included)



(Included)  
Allen Wrench



2 - People

## ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 25-12-05



## **CHECK BEFORE STARTING**

☐

### **Are you missing anything?**

Double-check all parts, hardware and accessories listed are all accounted for.

☐

### **Check out our Quick Tips!**

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

### **Should we send any replacements?**

Are there any irregularities or flaws in the parts? We can send replacements!

☐

### **Prep Time!**

Please review the assembly instructions and all diagrams prior to assembling.

# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



## Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



## Suitable Location

Assembling near the area of the intended location is highly recommended.



## Sufficient Space

Make sure you have enough space to move around during the assembly.



## Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



## Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


# ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY  
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly  
and insert screws or bolts into  
their respective holes.



Turn clockwise to tighten and  
only tighten when step is  
completed or when instructed  
to do so.



Use the appropriate hand tools  
or power tools for assembly.  
Select steps, such as tightening  
screws and/or bolts, may require  
hand tools to avoid causing  
damage during assembly.



Save the instructions and store  
any supplied tools for later  
maintenance.



After two weeks, check and  
tighten any loose hardware and  
repeat again every six months  
thereafter.

**IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.**


## ARM CHAIR



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.

### PARTS

(P1) - 2 PCS



CHAIR SEAT FRAME

(P2) - 4 PCS



FRONT LEG

(P3) - 4 PCS



BACK LEG

### HARDWARE

(H1) - 16 PCS



M6x60mm JCBC SCREW

(H2) - 16 PCS



SPRING WASHER

(H3) - 16 PCS



FLAT WASHER

(H4) - 1 PC




ALLEN KEY

(H5) - 8 PCS



NAIL LEG



## packed in 1 carton




### Please read instructions carefully

Remove all wrapping materials, staples and packing straps from the carton. Refer to Parts List and Hardware List and ensure they are complete before you start assembling. Place all wooden parts on a clean, flat and soft surface (e.g carpet or rug) to prevent parts from being scratched.

CAUTIONS: 1) DO NOT FULLY TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.

2) DO NOT OVER-TIGHTEN BOLTS AND NUTS .

3) KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.

| Carton | Designation            | Part List                                                                                   | Hardware List                                                                                          |
|--------|------------------------|---------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|
|        | CHAIR SEAT FRAME<br>P1 |  P1 x 2pc  |  H1 x <b>16pc</b>   |
|        | FRONT LEG<br>P2        |  P2 x 2pc  | M6x60mm JCBC SCREW                                                                                     |
|        | BACK LEG<br>P3         |  P3 x 4pc |  H2 x <b>16pc</b> |
|        |                        |                                                                                             | Spring Washer                                                                                          |
|        |                        |                                                                                             |  H3 x <b>16pc</b> |
|        |                        |                                                                                             | Flat Washer                                                                                            |
|        |                        |                                                                                             |  H4 x <b>1pc</b>  |
|        |                        |                                                                                             | Allen Key                                                                                              |
|        |                        |                                                                                             |  H5 x <b>8pc</b>  |
|        |                        |                                                                                             | Nail Leg                                                                                               |



COMPLETE ASSEMBLY

# ASSEMBLY INSTRUCTIONS


## SIDE CHAIR

### PARTS LIST (FOR 2 CHAIRS)

| NO. | COMPONENT        | QTY. |
|-----|------------------|------|
| P1  | CHAIR SEAT FRAME | 2    |
| P2  | FRONT LEG        | 4    |
| P3  | BACK LEG         | 4    |


### HARDWARE LIST (FOR 2 CHAIRS)


| NO. | DESCRIPTION                                                                                              | QTY. |
|-----|----------------------------------------------------------------------------------------------------------|------|
| H1  | JCBC SCREW M6 x 60MM  | 16   |
| H2  | SPRING WASHER         | 16   |
| H3  | FLAT WASHER           | 16   |
| H4  | ALLEN KEY             | 1    |
| H5  | NAIL LEG              | 8    |



COMPLETE ASSEMBLY


### STEP 1


|        |                                                                                     |
|--------|-------------------------------------------------------------------------------------|
| H1 x 8 |    |
| H2 x 8 |   |
| H3 x 8 |  |



### STEP 2

|        |                                                                                     |
|--------|-------------------------------------------------------------------------------------|
| H5 x 4 |  |
|--------|-------------------------------------------------------------------------------------|





## ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



### Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



### Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

**This product is intended for RESIDENTIAL USE ONLY and not for commercial use .**

### CARE AND MAINTENANCE

**SAFETY** - To avoid any risk of suffocation to children or animals, dispose off the plastic bags immediately.

**CLEANING** - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.

**FITTINGS** - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.