














ASSEMBLY INSTRUCTION




Loosely hand-tighten screws when fitting the table base; fully tighten all only after the full frame is aligned and assembled.

If you have any questions, please feel free to contact us at any time.
Official Consultation **Email: service@syimex.cn**

Parts & Tool List

① x2 	② x2 	③ x2 	④ x4 	⑤ x2 
⑥ x4 				
A x24+1  M6*15mm	B x8+1  Ø8*18mm	C x4+1  M6*12mm	Dx8+1  M8*10mm	E x4  Ø22*M8*16mm
F x3  Ø8*30mm	G x2  S4			

1



Assemble Part 4 in accordance with the enlarged detail drawing.


During installation, ensure the recessed hole marked by the arrow faces upward.

180°


x2



Dx4




Ex2



Gx1

2



Assemble Part 4 in accordance with the enlarged detail drawing.


During installation, ensure the recessed hole marked by the arrow faces upward.

180°


x2



Dx4




Ex2




Gx1

3




Ex3



Fx3

4




Push

Push


Cx4

5 x2

Notice: Tighten all screws to 50% tightness first, then push the two desktop panels, ensure no gaps, and fully tighten the screws afterwards.




Cx4




Gx1




5






6



7




8





9


From a different viewing angle, assemble in accordance with Step 8.




Notice: Tighten all screws to 50% tightness first, then adjust the components, and fully tighten all screws afterwards.




Ax6

Bx6

Gx2

10



If you find the floor is uneven, you can adjust the height of the "E" accessories so the table can be used normally.