


ASSEMBLY INSTRUCTION



NOTES:





























- The item is only intended to be used indoors. The product must be assembled and used in accordance with the provisions of the manual.
- It is recommended that assembly is undertaken by about 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined. Estimated assembly time is 30 minutes.

WARNING:

- **WARNING FOR YOUNG CHILDREN** - This product contains small components, please ensure that they are kept away from small children while assembling.


1

PARTS LIST

A	B	C	O	P	Q	R	S	T					
													
2PCS	2PCS	2PCS	1PCS	4PCS	6PCS	2PCS	2PCS	2PCS					
U	V	W	X	Y	Z	a	b	c	d	e	f	g	t
													
2PCS	2PCS	4PCS	1PCS	4PCS	2PCS	1/4*85 4PCS	1/4*50 8PCS	1/4*45 4PCS	1/4*37 2PCS	1/4*30 8PCS	1/4*23 4PCS	1/4*19 4PCS	2PCS
u	v	w	x	y									
													
1/4 4PCS	1/4 8PCS	1/4 2PCS	1/4 2PCS	1PCS									


2

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED




3


3




4



5




6




5


7




8




9



10



7



Warranty Information:

We warranty this product to be free from defects in materials. This warranty covers one year from the date of original purchase.