ASSEMBLY INSTRUCTION

REAR



FRONT

PART LIST

1 Top panel  1pc	2 Bottom panel  1pc	3-L Side Panel(left)  1pc	3-R Side Panel(right)  1pc	4 Division  1pc	5 Back Rail  1pc
6 Back Panel  2pcs	7 Door(Side)  2pcs	8 Door(Center)  2pcs	9 Shelf Panel  2pcs	10 Frame post  2pcs	11 Frame Rail  2pcs
12 Center post 1pc					

HARDWARE LIST

A MINI FIX SPREADING BOLT 24MM  36pcs	B MINIFIX HOUSING Ø15*12MM 6pcs	C MINIFIX HOUSING Ø15*10MM 30pcs	D WOOD DOWEL M8*30MM 32pcs	E CSK SCREW M3.5*12MM 52pcs	F CSK SCREW M4*30MM  16pcs
G SHELF SUPPORT  8pcs	H JCBC M6*40MM 1pc	I DOOR STOPPER  2pcs	J M4 ALLEN KEY  1pc	K HANDLE  4sets	L ADJUSTER 5pcs
M HINGES  4pcs	N HINGES  4pcs				

STEP 1



D X 14pcs	F X 4pcs	

STEP 2



F X 12pcs	L X 4pcs	

STEP 3



STEP 4



L X 1pc				H X 1pc	 J X 1pc		

STEP 5



A X 3pcs	B X 6pcs	D X 4pcs	

STEP 6





A X 4pcs	C X 4pcs	D X 2pcs	

STEP 7

FRONT VIEW







REAR VIEW



 A X 19pcs	C X 16pcs	D X 6pcs					

STEP 8



A X 10pcs	C X 10pcs	D X 6pcs					

STEP 9



STEP 10



E X 16pcs	M X 4pcs	N X 4pcs		 G X 8pcs			

STEP 11



E X 32pcs			

STEP 12



E X 4pcs	I X 2pcs	K X 4sets	

ASSEMBLY COMPLETE



ASSEMBLY INSTRUCTIONS

How to Concealed Hinges

Height Adjustment-helps you to adjust doors so they align at the top and bottom.



Note: Run your hand along the underside of the doors. You will easily feel which door are sitting lower than the others.

Depth Adjustment- Lets you bring a door into alignment with vertical surfaces such as drawers.



Note: Check to make sure you are not missing a door bumper. Missing door bumpers will cause your cabinet to look out of alignment.

Side Adjustment- adjusts gaps between doors and alleviates rubbing doors.



Note: Right Side Hinge: Clockwise moves door to RIGHT, CCW moves door to LEFT.
Left Side Hinge: Clockwise moves door to LEFT, CCW door to RIGHT.