


53373
53382

**CULINARY PLAY KITCHEN
CUISINE ENFANTS GASTRONOME
COCINA DE JUGUETE CULINARY
KULINARISK LEKSAKSKÖK**



**CALL US OR GO ONLINE
APPELEZ-NOUS OU ALLEZ EN LIGNE
LLÁMENOS O VISITE NUESTRO SITIO WEB
RING OSS ELLER SE ONLINE**



REV 12/08/2021

**ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE /
INSTRUCCIONES DE MONTAJE / MONTERINGSINSTRUKTIONER**

**FOR 24/7 ONLINE PARTS REPLACEMENT /
POUR LE REMPLACEMENT 24/7 DES PIÈCES EN LIGNE /
PARA SOLICITUDES ONLINE DE PIEZAS DE REPUESTO DE MANERA ININTERRUMPIDA /
FÖR RESERVDELAR ONLINE DYGNET RUNT**

parts.kidkraft.com

KidKraft, Inc.
4630 Olin Road
Dallas, Texas 75244
USA

customerservice@kidkraft.com

1.800.933.0771
972.385.0100

parts.kidkraft.eu

KidKraft Netherlands BV
Olympisch Stadion 8
1076 DE Amsterdam
The Netherlands

europecustomerservice@kidkraft.com

+31 20 305 8620
M-F from 09:00 to 17:30 (GMT+1)


BATCH CODE / CODE DE LOT / CÓDIGO DE LOTE / SATSKOD

We do our very best to ensure accuracy in every order, but occasionally we miss something. That's why our warranty covers every single part of your new product for 90 days after purchase.



Nous faisons de notre mieux pour assurer l'exactitude dans chaque commande, mais parfois nous manquons quelque chose. C'est pourquoi notre garantie couvre chaque partie de votre nouveau produit pendant 90 jours après l'achat.

Hacemos nuestro mejor esfuerzo para asegurar la precisión en cada orden, pero a veces se nos olvida algo. Por este motivo, nuestra garantía cubre cada parte de su nuevo producto por los próximos 90 días después de su compra.

Vi gör vårt bästa för att säkerställa noggrannhet i varje beställning, men ibland missar vi något. Det är därför vår garanti täcker varje enskild del av din nya produkt i 90 dagar efter köpet.




Parts and Hardware
 Pièces et matériel
 Partes y Piezas Para Instalación
 Teile und Befestigungsmaterial
 Delar och järndelar

F	x 2	J	x 2	N	x 10	R	x 1	V	x 2
									
16 mm		24 mm		27 mm					
G	x 22	K	x 12	O	x 8	S	x 1		x 1
									
10 mm		57 mm		24 mm		24 mm			
H	x 10	L	x 12	P	x 6	T	x 1		x 1
									
11 mm				43 mm		35 mm			
I	x 16	M	x 8	Q	x 9	U	x 1		
									
18 mm				52 mm					


Parts and Hardware
Partes y Piezas Para Instalación
Pièces et matériel
Teile und Befestigungsmaterial
Delar och järndelar

All hardware dimensions are approximate.
Todas las dimensiones de las herramientas
son aproximadas.
Toutes les dimensions du matériel sont approximatives.
Alla järndelars mått är ungefärliga


1




2




3




4




5




6




7




8




9




10




11




12




13




14




15




16




17




18




19




20




21




22




23




24




25




26




27




28




29




30




31




32




33




34




35




36




37




38




39




40




41



42




43




Wall Anchor
Dispositif d'ancrage au mur
Anclaje de Pared
Wandanker
Väggfäste

A1

The hole is located on the floor panel
 Le trou est situé sur le panneau de plancher
 El agujero se encuentra en el panel del suelo
 Das Loch befindet sich auf der Bodenplatte
 Hålet finns på golvpanelen



A2



⚠ WARNING:
 Do not install on a wall where items can fall off and injure a child.

⚠ AVERTISSEMENT:
 Ne pas installer sur un mur duquel d'autres objets risquent de tomber et blesser un enfant. A monter par un adulte.

⚠ ADVERTENCIA:
 No instale en una pared donde otros artículos se puedan caer y lastimar a un niño.

⚠ VORSICHT:
 Bitte nicht an einer Wand anbringen, wo Dinge herunterfallen und Kinder verletzen könnten.

⚠ VARNING:
 Installera inte på en vägg där föremål kan lossna och skada barnet.