




Assembly Instructions
Nightstand with Concealed Compartment








Step 1:
Place the Right Panel (C) onto a soft surface. Attach Shelf (D), Top Shelf (E) and Bottom Frame (F) into Right Panel (C) by using Large screws (RF10052) as per diag 1.




Put the Back Crossbars (I), Front Crossbar (H) and Bottom End (J) into the unit as per diag 2.









Attach the Front (K), Left (L), Right (M), Back (N) and plate (O) together by using screws (RF10019). Then, attach Handle (RF40140) into the Front (K) of drawer as per Diag.5.






WARNING. The hidden compartment is NOT a security safe. The inner contents in the hidden compartment are the sole responsibility of the user and are to be stored at the user's discretion. Regardless of loss, seizure, damage, or changes in condition to the inner contents of the hidden compartment, the manufacturer is not liable for the contents stored in the hidden compartment.

How to use the concealed compartment




The hidden compartment is built in, shipped with the locking bolt (if installed), and is disengaged and unlocked. In order to engage the hidden compartment lock, please remove the sticker which blocks the bolt (see the diagram 8).




This sticker identifies the designated position. Place the magnetic key here to unlock the concealed drawer.

* Before removing the sticker, please note the designated position.



Unlock and Open: place the magnetic key onto the assigned position shown above to unlock and pull out the drawer as per diagram 9.



Close and Lock: close the drawer and remove the magnetic key from the assigned position to lock the drawer as per diagram 10.

7/7