


Storage Cabinet C User Manual


INTRODUCTION

Thank you for purchasing our products. Committed to providing customers with the best quality products and service has always been our lifelong goal. Before using the product, please read this instruction manual carefully to ensure correct use. Keep the instruction manual in a place where the user can find it at any time.


PRECAUTIONS


- 1. There are many components and accessories in the package. Each component and accessory is labeled with a letter or a number, check carefully before using any of them. Keep them away from children to
- 2 prevent accidents.
 - Please install the product on a clean and soft underlay (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.
- 3. The main components of the product is relatively heavy. Please pay attention to safety during installation.
- 4. The product is not stable during installation. Please do not move it randomly before it is completely installed.
- 5. If you have any questions during installation, please contact the customer service in time.
- *PLEASE BE SURE TO FOLLOW THE INSTALLATION STEPS IN THE MANUAL TO AVOID UNNECSSARY LOSSES CAUSED BY IMPROPER INSTALLATION.
- *IF YOU NEED FUTHER ASSIATANCE,PLEASE CONTACT THE CUSTOMER SER-VICE ONLINE.





HARDWARES LIST										
Α	Ø5*25mm	В	Ø15*11mm	C Ø23mm	D	Ø8*30mm	E Ø5	5x16mm	F	Ø6*50mm
	x20 pcs		x20 pcs	x20 pcs		x26 pcs		x12 pcs		x8 pcs
G16	6x16*10.5mm	Н	Ø3x17mm	J 128*12*38mm	K	5/32"x22mm		straight arm door	N	Ø3.5*14mm
							ninge (or	uter cover)		
	x16pcs		x16 pcs	x4 pcs		x8 pcs		x8 pcs		x48 pcs
0	M4	Р	10g	Q ø8.5x30	R	Ø4x18	S ø	1x25	Т	140x25
						(}				
	x1 pcs		x1 pc	x2 pc		x2 pc		x2 pc		x2 pc






5

YOU WILL NEED

Bx1




6

FX4


F 2

3




9

YOU WILL NEED
Ax4




10

YOU WILL NEED
Ax14



11


YOU WILL NEED
Bx4



12


YOU WILL NEED

Bx1




13

YOU WILL NEED
Bx4




14

YOU WILL NEED




15



16


YOU WILL NEED
Bx4



17


YOU WILL NEED

Gx16 Hx16




18

YOU WILL NEED
Ex12




19




9//

20


YOU WILL NEED
Mx4 Nx8



YOU WILL NEED					
Jx2	Kx4				





YOU WILL NEED				
Jx2	Kx4			




YOU WILL NEED


Nx16










This is used to adjust the door panel in the left and right direction.






This is used to adjust the door panel in the front and back direction: Loosen screws of I according to the diagram, and then tighten screw after adjusting the door panel to the proper position.






This is used to adjust the door panel in the left and right direction.



This is used to adjust the door panel in the front and back direction: Loosen screws of I according to the diagram, and then tighten screw after adjusting the door panel to the proper position.

25


YOU WILL NEED
Cx20



26


YOU WILL NEED					
Tx2	Rx2				

Attach anti-tipping straps to the back of the sideboard.



27

YOU WILL NEED					
Qx2	Sx2				



Furniture must permanently fixed to the wall stud with included anti-tipping device to prevent the furniture from tipping over.

- · Mark the drill position on the wall with a pencil.
 - · Drill a small hole on the marked position.
 - Insert a wall anchor into the drilled hole.
- · Fixed the anti-tipping strap to the wall with provided screws.