



**MERRY
CHRISTMAS**

Artificial Holiday
Christmas Tree

! NOTICE

Please retain these instructions for future reference.

Firmly secure all screws before use.

Product is intended for indoor use only.

Do not place this tree in a wet location.


This seasonal product is not intended for permanent installation or use.

Do not use or store this item in the proximity of open flame, flammable/combustible chemicals, or other strong heat sources.

If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.

Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

HARDWARE




1 PERSON
ASSEMBLY



UP TO 120 MIN.
ASSEMBLY

PARTS



NOTE: Wires may come wrapped around frame pieces. Locate and unwrap wires before assembly.




Please remove the caps on the end of the poles before assembly.

PRODUCT ASSEMBLY

1

Assemble the tree.

NOTE: Bottom section is wider than the middle section.
Make sure sections are arranged in the correct order.




PRODUCT ASSEMBLY

2

Connect all the corresponding plugs.

Spread out the branches and arrange them to your preference.

Insert the bottom plug into a wall outlet to turn the lights on.



CLEANING & STORAGE

- Store this tree in a cool and dry place away from heat and moisture.
- Before putting this tree in storage, do the following:
 - Completely remove all decorations.
 - Clean the tree with a slightly damp cloth and let it dry naturally.
 - Raise all branches to original upright position; make sure not to damage any branches in the process.