


ITEM NO.ZX0183



NOTE:

This brochure contains IMPORTANT safety info. Please read and keep for future reference.

MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.

Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :

This brochure contains IMPORTANT safety info. Please read and keep it for future reference.




Weight Limitation

200 LBS



Installation:
60 minutes.



Two Person



Before You Start

Please follow the steps below:



Unbox the package and check if all parts and accessories are complete.



If you find something missing, stop assembly and contact your supplier immediately.



Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.




NOTE: Should be assembled on soft surface to keep balance.

After-Sales Service


- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.

Exploded Diagram




Parts List

A ×1




Top panel

B ×1




Bottom panel

C ×1




Left side panel

D ×1




Right side panel

E ×1




Middle panel

F ×2



Adjustable Shelf

G ×1




Back panel

H ×4



Legs


I ×1



Mid-leg


Parts List

J ×1




Left door

K ×1




Middle Left door

L ×1



Middle Right door

M ×1




Right door



Hardware Liste

1 x4



Door stop

2 x4




Screw
Ø4*39mm

3 x4



Wall anchor

4 x2



Tie

5 x4




Anti-tip
component

6 x4



Screw
Ø4*20mm

7 x42+4



Screw
Ø3*15mm

8 x8+1




Screw
Ø6*45mm

9 x48+4




Screw
Ø4*15mm

10 x4



Hinge

11 x4



Hinge

12 x8



Shelf pin

13 x1



Screwdriver

14 x1




Allen key

Assembly Instructions

Step 1

1. Install part (I) on of bottom panel (B).
2. Insert screw (8), install leg (H) on of bottom panel (B), then tighten the screw with an Allen key (14).


8	 x 8	Ø6*45mm
14	 x 1	Allen key



Step 2

1. Insert panel (C/D/E) into the corresponding hole of bottom (B), make sure all holes aligned and use allen key (14) to tighten it as picture show.


14	 x 1	Allen key
----	---	-----------



Step 3

1. Use screw (7) to attach Door stop (1) to the corresponding hole of panel (A), tighten screw with screwdriver (13).


7	 x 16	Ø3*15mm
1	 x 4	Door stop
13	 x 1	Screwdriver



Step 4

1. Install the top panel (A) into the corresponding holes in the pre-assembly step 3, make sure all the holes line up and tighten it with (14) allen key as shown in the picture.


14	 x 1	Allen key
----	---	-----------






Step 5

1. Install part (G) into the preassembled step 4, make sure all holes aligned and use screw (7) to attach them, tighten screw (7) with screwdriver (13).

7	 x 26	Ø3*15mm
13	 x 1	Screwdriver



Step 6




Attention:
Before the next step, adjust the feet of the
locker to keep it level.

Step 7

1. Insert shelf holder (12) to the unit pre-assembled at step 6 and attach the part (F) to them.


12	 x 8	Shelf pin
----	---	-----------



Step 8

1. Use screw (9) to attach the hinges (10) to door panel (J)&(M), tighten screws with screwdriver (13)
2. Use screw (9) to attach the hinges (11) to door panel (K)&(L), tighten screws with screwdriver (13)


9	 x 16	Ø4*15mm
10	 x 4	Hinge
11	 x 4	Hinge
13	 x 1	Screwdriver



Step 9


1. Use screw (9) to attach door (J&K&L&M) to pre-assemble unit at step 8 ,tighten screw (9) with screwdriver (13) .

9	 x 32	Ø4*15mm
13	 x 1	Screwdriver




Step 10


1.If you can't open the door smoothly, please adjust it as shown.




Concealed hinges are three-way adjustable:




Horizontal
by screw adjustment!




Concealed hinges are three-way adjustable:




In-and-out
by loosening the hinge arm
mounting screw or via cam
adjustment!



Concealed hinges are three-way adjustable:



Vertical via slots in
the mounting plate
or via cam adjustment!



Hinge adjustment method




Scan for adj video

Step 11

1. Use screw (6) to attach Anti-tip component (5) to panel (G), make sure all holes aligned and tighten screw (6) with screwdriver (13).



6	 x 4	Ø4*20mm
5	 x 2	Anti-tip component
13	 x 1	Screwdriver




Step 12

1.Install Anti-tip device (5) to the wall in this step.


5	 x 2	Anti-tip component
2	 x 4	Ø4*39mm
3	 x 4	Wall anchor
13	 x 1	Screwdriver



1.Drill a hole in the wall with an electric drill.



2.Tap the plastic wall anchor into the hole with a hammer.



3.Secure the Anti-tip device (5) to the wall with screws (2)

Step 13

1. Let the plastic belt (4) pass through the both part (5) and pull tightly.

4	 x 2	Tie
---	---	-----

⚠ WARNING




Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



***This is a permanent label.
Do not remove!***



WARRANTY

1. We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed.
2. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive.
3. Replacement parts by purchasing them with our company if they are available.

Are you having difficulty
With assembly? Missing parts?
Please send email with your order No to
HKXIMU2026@126.COM
For return, please check the return policy with
the retailer or market place you bought from.

Appreciate your purchasing from us.
Pop up your life by our furniture piece!