


MANUAL INSTALLATION

OVERFLOW



1	Clicker Plug assembly (fixed plug)
2	Waste ferrule (Fixed plug)
3	Waste flange
4	Waste seal
5	Waste body
6	Overflow cover
7	Overflow ferrule
7	Overflow ferrule
8	Overflow flange
9	Overflow seal
10	Overflow body
11	Overflow flexible coupling
12	ABS pipe 316mm
13	Swept tee
14	ABS pipe 135mm
14	ABS pipe 135mm

MANUAL INSTALLATION

OVERFLOW

