



ASSEMBLY INSTRUCTION




+ Parts Included


- ① SOFA BASE
1PC



- ② LEG
4PCS



- ③ MIDDLE LEG
1PCS



+ Do Not Use Power Tools



+ Suggested Adults



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- Part # - Sofa Base
- Part # - leg
- Part # - Middle leg

Do not assemble if any of the following Hardware parts missing:

- Part # - Allen Wrench
- Part # - Bolt
- Part # - Washer

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Hardware Included

- A ALLEN WRENCH**
Ø5/16 *60MM 1PC



- B BOLT**
M6*25MM 12PCS






- C WASHER**
M6*16MM 12PCS



ASSEMBLY INSTRUCTION

1



2

