

Kids Pod Swing Installation Manual



WARNING:

Failure to follow these directions and warnings can result in serious injury or product damage.

- (1) Loading capacity 176 lbs.
- (2) Suitable for children between 3-9 years old.
- (3) Please hang the chair on the stable reliance.
- (4) Children must be accompanied by adults when in use.
- (5) The hanging height within 40 cm to prevent accidental fall.

NOTED:

- ⊗ Excessive, violent rotation will shorten the service life of the hammock.
- ⊗ Do not over inflate when using.
- ⊗ In order to increase the service life, avoid rain outdoors.
- ⊗ This hanging chair is specially designed for children. In order to enhance the service life, it is recommended that teenagers over 15 years old do not use it for a long time.

Pod Swing x 1 Pcs	Ceiling Mount x 1 Pcs	Snap Hook x 1Pcs	Nylon Strap x 1 Pcs
	PVC inflatable Cushion x 1Pcs	Screws x 2 Pcs	Screws x 2 Pcs
		For Wooden Ceiling 	For Concrete Ceiling

Installation Method:



Verify that all parts are included.



Insert the PVC inflatable cushion.



Inflate the cushion up to 60%-80%.



Install the ceiling mount and hook on the ceiling.



Adjust the height, and then use nylon strap to hang the pod swing.

⚠ The hanging height within 40 cm to prevent accidental fall.