


# FOLDING COOKING GRATE

Review all information before using this product. Save this document for future reference.



**CARE & STORAGE:** Wipe down surfaces with clean water and a mild soap/vinegar and a grill brush (avoid steel wool), then lightly coat with vegetable oil to prevent sticking and rust. For deep cleans, use soap and water or baking soda, but never bleach or harsh acids. Allow the unit to air-dry. Thoroughly dry after cleaning to maintain a non-stick, rust-free surface.

Manufacturer is not liable for damage resulting from general use, misuse, and/or environmental conditions.

**NEVER USE CHEMICAL-BASED CLEANERS** as doing so may damage the product and/or ignite a flame during the next use.

**WARNING:** THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, TOUCH-UP PAINT, OR CLEANING PRODUCTS.

*If the product was damaged during transit, please contact our customer service team through one of the methods mentioned at the top of page 1. Please have the item number and order information ready to expedite response time.*

**Any modification to the product or failure to follow recommended care will void the product warranty.**

**⚠️ WARNING:** Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.