

# USER GUIDE



## 5-TIERS SHOES RACK

# SAFETY & WARNINGS


## Warning

- The product contains small parts and sharp objects, please be careful during assembly and keep children away.
- Keep plastic bags away from children in case of suffocation.
- Please make sure to keep the item away from extreme conditions (such as high humidity, high temperatures, intense sunlight, excess water, etc.)
- Do not place any sharp objects or corrosive materials on the product to avoid any damage. In cases of placing sharp footwear like ice skates, please use blade guards.
- Please do not force large size shoes into the product in order to avoid deformation.
- Please do not place overweight objects, do not stand on the product and keep children away from jumping on the product.


## Important

- Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
- Do not over tighten screws and bolts to avoid stripping.
- Please use hand tools to assemble this product. Do not use power tools.
- Do not sit on the shoe rack. Do not drop heavy items on the shoe rack.
- Do not move the shoe rack while loaded.
- Do not move the shoe rack by lifting the poles, use the handles at the top of each side frame.


# COMPONENTS



A x 12PCS




B x 8PCS



C x 8PCS



D x 4PCS



E x 6PCS



F x 2PCS

# INSTALLATION

## Step 1

Connect the right ends of four A to E.




## Step 2

Connect the left ends of four A to E.



### Step 3

Insert four B into each hole in the four corners of E.




### Step 4

Repeat the above steps to get the four-tier shoe rack.



### Step 5

Complete the stand of the shoe rack by inserting four C into each hole underneath the four corners of E. Connect four D to the bottom of the four C.



### Step 6

Install the top shelf stopper by using four C and two F.



# CLEANING & CARE

- Clean the product with a dry soft cloth. Avoid cleaning the product with a hard item or chemically unsuitable product.
- Please make sure to keep your items and shoes clean before placing them.
- In case of using a mildly wet cloth, please make sure to dry the surfaces immediately after cleaning.
- When disassembling the item, please make sure to use the same tools required for assembly.
- If something is stuck on the surfaces, do not use abrasive tools to remove them, as these could leave scratches or marks. Please use lint-free cloths or sponges instead.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.