


ASSEMBLY INSTRUCTIONS

ITEM:LDPB5D




LDPB5D

Please scan this QR code and contact us if you have any questions! If your products has damages, missing parts, problems with installation and use, or you are not 100% satisfied with our products, please scan the QR code and contact us!

Email:vimity-service@outlook.com

SUPPORT: + 18882062161

PACKAGE INCLUDE








SUPPORT: + 18882062161

PACKAGE INCLUDE

CODE	DESCRIPTION	QTY
1	Top Panel	1
2	Bottom Panel	1
3	Left Side Panel	1
4	Right Side Panel	1
5	Upper And Lower Back Panel	2
6	Middle Back Panel	1
7	Wood Strip	6
8	Upper Drawer Panel	1
9	Middle Drawer Panel	3
10	Lower Drawer Panel	1
11	Drawer Left Side Panel	5
12	Drawer Right Side Panel	5
13	Drawer Back Panel	5
14	Drawer Bottom Panel	5
15	Drawer Bottom Strip	5


SUPPORT: + 18882062161

PACKAGE CONTENT


Ø8X30MM  A 20X+1	Ø3X11MM  B 60X+2	Ø4X35MM  C 30X+1	Ø15X10MM  D 41X+2
Ø3.5X12MM  F 34X+1	 G 41X+2	 H 2X	 K 5X
Ø4X50MM  L 4X	 M 10X		

SUPPORT: + 18882062161


How to use the cam lock system




1. Screw cam bolt into panel




2. Push cam into panel - arrow feature on cam top points to panel edge



3. Align cam bolt(s) with cam(s) and insert all the way into cross-bored hole(s)




4. Rotate cam(s) clockwise 190°-230° to lock panels together



5. Panels should be tight against each other and connection should be rigid

Insert the wood dowel [C] at least half way by tapping lightly with a rubber mallet, IF NECESSARY.








⚠ WARNING

- Unit must be placed on a level surface or leveled with included hardware (when applicable).
- Do not sit or stand on or allow children to climb, sit or stand on the assembled product.
- For safety reasons, it is imperative that this unit be mounted to the wall.
- Do not use without installing the tip restraint.
- Unit can tip over causing severe injury or death.
- Do not exceed the recommended weight limits.
- Evenly distribute the weight on each level and always keep the heavier loads on the bottom.
- Before cutting, drilling or hammering into any wall or floor surface, verify the location of electrical, plumbing and gas lines. Cutting may cause serious injury.


SUPPORT: +18882062161

STEP 1




SUPPORT: + 18882062161

STEP 2





STEP 3





SUPPORT: + 18882062161
-6-

STEP 4







STEP 5



SUPPORT: + 18882062161
-7-

STEP 6




SUPPORT: + 18882062161
-8-

STEP 7





F

X34




SUPPORT: + 18882062161

STEP 8





STEP 9





SUPPORT: + 18882062161

STEP 10



X5





STEP 11



X5

SUPPORT: + 18882062161
-11-



STEP 12



X5



SUPPORT: + 18882062161

STEP 13



SUPPORT: + 18882062161
-13-

STEP 14



⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



*this is a permanent label.
Do not remove!*

SUPPORT: + 18882062161
-14-