










Double Egg Rocking Chair


Installation Instructions



Scan to get a quick assembly guide,
dedicated support, plus member
access to exclusive perks
& extended warranty.


Parts List

Parts List								
Accessories								
	A	1	B	1	C	1	D	1
								
	E	1	F	1	G		2	
								
	H	2	I	1				
Tools								
	M6,55mm 16		M6,40mm 8		M6,30mm 8		Wrench	
					Notice: Please check the accessories before installation, if there is any problem, feel free to contact us!			
	Hexwrench		Ratchet Wrench					




Step1-1:

Assembling the seat part of the chair.
Use 6 (M6,55mm) screws.



Notice:

- 1-Please don't tighten all screws completely at beginning!
- 2-Fully tighten after completing the chair seat !!




Notice:

- 1-Please don't tighten all screws completely at beginning!
- 2-Fully tighten after completing the chair seat !!

Step 2:


Use 8 (M6,30mm) screws to secure the leg accessories (G) to the chair seat.

**Notice:**

Position G: short side on CD, long side on AB.

Step 3:


Use 8 (M6,40mm) screws to secure accessory (H) to accessories (G).

**Notice:**

- 1-Please don't tighten all screws completely at beginning!!
- 2-Fully tighten after completing the chair legs !!

Notice:


The iron sheets on both sides of accessory (H) are tilted.
When installing accessory (H), please ensure that
the outward-tilted iron sheets are facing the rocker's feet.




Step 4:

Tighten all the screws.

Place accessory (I) on the chair.



Double Egg Rocking Chair



ONLINE SUPPORT

Please read the installation guide carefully before installation
If you have any questions during the installation process
you can contact us and we will provide you a detailed guidance

Online Support: outdoorservice@kannelfurniture.com