



PACK-AWAY™ 20 COLLAPSIBLE FIRE PIT

QUICK ASSEMBLY STEPS



STEP 1

Insert one of the bottom panels into one of the sides.



STEP 5

Lift up the other side of the third panel and hook it to the other adjacent panel.



STEP 2

Insert the other bottom panel.



STEP 6

Insert the fourth panel by lifting up one side of the panel and hook it together with the adjacent panel.



STEP 3

Tilt the side panel with the two bottom panels inserted to make the bottom panels slant upwards, then insert the opposite side panel.



STEP 7

Lift up the other side of the fourth panel and hook it to the other adjacent panel.



STEP 4

Insert the third panel by lifting up one side of the panel and hook it together with the adjacent panel.



STEP 8

Assembly completed.



PACK-AWAY™ 20 COLLAPSIBLE FIRE PIT

INSTRUCTIONS AND CAUTIONS

WARNING

To minimize the risk of serious injury or death from fire or explosion, read and follow all instructions and safety precautions below when using your Coleman® Pack-Away™ Collapsible Fire Pit.

SAFE LOCATION

- Only use outdoors (with no cover) under adult supervision.
- Keep children and pets a safe distance away from fire pit while in use.
- Use caution when handling, parts are heavy and can cause damage or harm if dropped.
- Do not use on a boat or in an RV.
- Only use on non-combustible surfaces.
- Keep away from bushes, shrubs, tree branches, and anything that could catch on fire.
- Never touch while fire is in fire pit.
- Only use firewood or manufactured fire logs as fuel.
- Keep gasoline and other flammable substances away from fire pit.
- Do not place objects against fire pit.
- Allow to completely cool before disassembling and storing.
- Store in dry area, away from liquids and moisture.

FOR SAFE USE

- Do not touch fire pit, embers, or ash until completely cool.
- Use caution when leaning over fire pit.
- For best results, do not overfill fire pit.
- Do not use water to extinguish the fire.
- Do not use fire pit if damaged or broken.
- Cover fire pit when not in use.



Distributed by:
BackHome Products LLC.
8321 E. Evans Road, Suite 101
Scottsdale, AZ 85260

CUSTOMER SERVICE

Contact BackHome Products at
833-953-9696,
info@colemanbackhome.com,
or on our site at
colemanbackhome.com.

© 2024 BackHome Products LLC.

Coleman® is a registered trademark of
The Coleman® Company, Inc.,
used under license.



WARNING: The combustion products emitted when this product is burning can expose you to chemicals including carbon monoxide which is known by the State of California to cause birth defects or other reproductive harm. For more information go to p65warnings.ca.gov.

Limited 1 Year Warranty. BackHome Products warranty each and every Coleman® Pack-Away™ Collapsible Fire Pit product to be free of manufacturing defects, and we will replace with a new product, at our option, any genuine Coleman® Pack-Away™ Collapsible Fire Pit product sold by an authorized retailer, with proof of purchase by the original owner, that is deemed defective. BackHome Products does not warranty its products against normal wear or misuse. If your Coleman® Pack-Away™ Collapsible Fire Pit product was damaged due to misuse, our customer service team can analyze the damage and may be able to suggest options for the customer to remedy. If your Coleman® Pack-Away™ Collapsible Fire Pit product is unable to be repaired after misuse, we will extend a one-time courtesy offer, allowing you the option to purchase a new Coleman® Pack-Away™ Collapsible Fire Pit product for 50% off of our original MSRP price (excludes sale pricing) on BackHome Products website on a new identical Coleman® Pack-Away™ Collapsible Fire Pit product. Warranty claims are not applicable for countries outside the U.S. and Canada.