

Use and Care Instructions

Pre-Assembly

Our products ship unassembled. Assembly is easy, and requires common household tools if the necessary tools have not already been provided with the hardware.

Before starting, inventory all hardware as stated on the assembly instructions, and carefully read the instructions to familiarize yourself with all parts and processes before starting assembly.

Use Instructions

Our products are carefully designed for personal use only. Any commercial use of the product must be approved prior to purchase, and may be subject to a termination in warranty.

Care Instructions

General Care

When moving your furniture, carefully lift the product. Dragging furniture can cause damage to both the product and your floors.

Do not expose your furniture to strong sunlight, which can cause discoloration, or to extremem heat, cold, or humidity, which can cause furniture to swell or warp.

Clean spills immediately. Blot - do not rub - all spills using a clean, dry white cloth (preferably cotton).

Upholstery

Regularly flip, rotate, and fluff removable cushions to ensure even wear and increase the longevity of the seating.

Removable cushion covers should be cleaned the same way as the body of the product to ensure even coloration.

Vacuum regularly to remove dust. While difficult to see, dust can soil and abrade the upholstery.

To clean, immediately blot siplls with a clean, white dry cloth (preferably cotton). Remove as much of the spill as possible. Blot with a mild soap and water solution, then blot to remove any remaining moisture.

Use and Care Instructions

Wood

Protect surfaces from moisture with coasters, table cloths, and the like whenever in use. If moisture does touch the surface, wipe immediately with a dry, soft cloth.

Protect surfaces from scratches by avoiding dragging items, and by using felt pads, coasters, place-mats, and the like whenever possible.

Rotate product if possible to allow for even wear and exposure of surface.

Dust regularly with a dry, white cloth. If the top is grooved, make sure all moisture is removed to prevent damage.