


TV Stand

Assembly Instructions - Please keep for future reference



Dimensions

Width-66.929inch

Depth-15.748inch

Height-27.165inch



WARNING



This product is NOT a Clothing Storage Unit (CSU).
DO NOT use it for clothing storage.
Improper use may cause furniture tipover.

Important - Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightened properly.

WARNING
In order to help prevent overturning –
please follow these instructions







To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Components-Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required

(A)  6*35mm Cam Bolt x 36	(B)  15*10mm Cam Lock x 36	(C)  6*30mm Dowel x 20	(D)  4*35mm Screw x 8
(E)  3.5*14mm Screw x 50	(F)  Layer plate support x 8	(G)  Anti-tilt Angle iron x 2	(H)  13*38mm Door stop x 2
(I)  Phillips screwdriver x1	(J)  Back panel buckle x 20	(K)  Plastic expansion bolt x 2	(L)  Metal handle x 4
(M)  4*22mm Screw x 8	(N)  Hinge x 8	(O)  3*16mm Screw x 20	(P)  3.5*15mm Screw x 4
(Q)  EVA pad x 9			

Tools required



Phillips screwdriver


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.








The joint is now secure.

4




Assembly Instructions




 1700*400*14mm ①X1	 1700*400*14mm ②X1	 595*397*14mm ③X1	 595*397*14mm ④X1
 826*267*2.5mm ⑤X2	 595*397*14mm ⑥X1	 589*404*17mm ⑦X2	 589*404*17mm ⑧X2
 810*350*14mm ⑨X2	 365*70*14mm ⑩ X2	 1694*70*14mm ⑪ X1	 1694*70*14mm ⑫ X1
 816*85*14mm ⑬ X2	 365*70*14mm ⑭ X1	 826*267*2.5mm ⑮ X2	

Assembly Instructions

Step 1




(A)




6*35mm Cam Bolt x 4

Step 2



(B)




15*10mm Cam Lock x 2

(C)




6*30mm Dowel x 3


Step 1



Step 2




Step 3




Assembly Instructions

Step 3




Step 4




Assembly Instructions

Step 5




Step 6




Assembly Instructions

Step 7




(A)




6*35mm Cam Bolt x 8

Step 8




(B)




15*10mm Cam Lock x 8


Step 1



Step 2








Step 3





Assembly Instructions






Step 9



Step 10



Step 3






Be careful! At least two people are required

180° here.

Assembly Instructions

Step 11






6*30mm Dowel x 6




Layer plate support x 8


Step 12



6*35mm Cam Bolt x 6




13*38mm Door stop x 2




3.5*15mm Screw x 4

Assembly Instructions

Step 13



(G)



Anti-tilt Angle iron x 2


(E)




3.5*14mm Screw x 2

Step 14


Step 1




Step 2




Step 3



(B)





15*10mm Cam Lock x6





Assembly Instructions

Step 15




Step 16




Assembly Instructions

Step 17



Assembly Instructions

Step 18




(E)




3.5*14mm Screw x 16

(N)




Hinge x 8

Step 19



(L)



Metal handle x 4


(M)



4*22mm Screw x 8

Assembly Instructions

Step 20




E



3.5*14mm Screw x 16

Assembly Instructions

Step 21




E





3.5*14mm Screw x 16

HINGE ADJUSTMENTS



When the hinges are installed, you can refer to the pictures to adjust the screws of the doors till it's perfect.





1. Adjust the screws shown in Figure 1 to adjust the door up and down.



2. Adjust the screws shown in Figure 2 to adjust the door left and right to the right position.



3. Adjust the screws shown in Figure 3 and pull the door back and forth so that it can be opened smoothly.



4. After the adjustment is complete, secure the remaining two screws to secure the door in place.

Assembly Instructions

