


10ft Offset Patio Umbrella

USE AND CARE GUIDE



Questions, problems, missing parts?

Before returning to the store, please contact our Customer Service

THANK YOU

We appreciate the trust and confidence you have placed in our products by purchasing this patio umbrella. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs.

The Weighted Base Sold Separately

Table of Contents

Table of Contents	01
Important Safety Information	02
- Product Caution	02
- Safety Warnings	02
Warranty	03
Pre-Installation	03
- Planning Installation	04
- Hardware Included	05
Installation	06
Care and Cleaning	22

Important Safety Information

Product Caution

Before You Start

- Important: Retain these instructions for future reference.
- When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.
- Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent it from scratching.
- Check the pack and make sure you have all the parts listed.
- Do not use power tools to construct this product.
- Ensure that this product is fully assembled as illustrated before use.
- Before you begin, ensure all pieces are accounted for and the stone pavers or bolts are ready to secure base. Read all instructions before you begin. You may need a friend to help you.

Safety Warnings

- Please keep children out of the assembly area before assembly.
- Hold the umbrella upside down and shake gently to separate the umbrella ribs. If necessary, carefully pull the ribs apart to free them.
- Slowly turn the crank to open the umbrella. Make sure that the ribs are not stuck together.
- This umbrella unit is heavy, and may require two adults for safe assembly.
- Never use this product as a support. Do not shake, lean, or climb on the product at any time.
- This is not a permanent structure and should be taken down during adverse weather conditions including but not limited to high winds, heavy rains, and snow.
- Do not attempt to lower your umbrella while the canopy is locked in the open position. This could cause harm to both yourself and your umbrella.
- Do not use umbrella over or near harsh chemicals or open flames including but not limited to chlorine, grills, barbecues and fire pits.
- When adjusting the umbrella, make sure that no person(s) or item(s) are close to the umbrella. Allow ample height to avoid damage to your umbrella during assembly and usage.
- IMPORTANT: PRIOR TO USING THE TILT FUNCTION. To avoid personal injury or damage to the umbrella, make sure the area behind you is clear and free from any furniture or structure.
- Umbrella base tube has 2.5° backward to the vertical for engineering purpose.

Warranty

1 YEAR FRAME AND FABRIC WARRANTY

What Is Covered

We warrant the frame and fabric to be free of manufacturing defects to the original purchaser for one year.

What Is Not Covered


It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchase parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Pre-Installation


Planning Installation

To prevent damage, place all parts on a soft surface during assembly. Remove all protective caps before beginning assembly.


Hardware Included




A




B



C




D




E




F






G




H



J




**1****(4pcs)****M10X30MM****2****(4pcs)****M10X22MM****3****(8pcs)****ø11****4****(1pc)****M6X10MM****5****(1pc)****S5****6****(1pc)****S8**

Part	Description	Quantity
A	Lower Bracket	1
B	Upper Bracket	1
C	Base Tube	1
D	Rotating Base	1
E	Umbrella	1
F	Lower Umbrella Pole	1
G	Hand Crank	1
H	Base Cover	1
J	Cover Plate	1
1	Bolt(M10x30MM)	4
2	Bolt(M10x22MM)	4
3	Washer	8
4	Bolt(M6x10MM)	1
5	Allen Wrench S5	1
6	Allen Wrench S8	1



STEP 1.1



1. Be mindful of the protective packaging in the umbrella tray. It MUST be removed before opening.
2. Press the handle and pull out the (C) Base Tube

**E****C**

STEP 1.2

Attach the (B) Upper Bracket onto the (A) Lower Bracket.


NOTE: This umbrella should be set up in its desired location to avoid moving it after assembly.



STEP 1.3

1. Attach the part (D) Rotating Base to the Brackets using (1) M10x30mm Bolts and (3) Washers, then tighten it with (6) Allen Wrench S8.




2. Attach the part (C) Base Tube to the (D) Rotating Base using (2) M10x22mm Bolts and (3) Washers, then tighten it with (6) Allen Wrench S8.



STEP 1.4

1. Fasten (J) Cover Plate to (H) Base Cover;
2. Slide the fastened (J) Cover Plate and (H) Base Cover together onto (C) Base Tube and cover (D) Rotating Base.

NOTE: This umbrella requires a 309 lb. base. Our umbrella base is sold separately. The weighted base is NOT included.


**H****J**

STEP 1.5

Slide the (F) Lower Umbrella Pole onto (C) Base Tube.








F



STEP 1.6

Align holes (E) umbrella and (C) Base Tube; Firmly insert the (E) umbrella onto (C) Base Tube and secure it with (4) M6x10mm Bolt, then tighten with (5) Allen Wrench S5.


**E****4 (1pc)****5 (1pc)**

STEP 1.7

Compress the handle and move the arm up. Insert the part (G) Hand Crank.




G



STEP 1.8

Slowly turn the crank clockwise to open the canopy.



Compress the handle and move the arm up. Release the handle to lock it in your desired position.



STEP 1.9

Rotating Umbrella


1. Compress the pedal on the (D) Rotating Base to rotate the umbrella 360°.
2. Adjust the umbrella to the appropriate position and release the pedal to stop rotating.



STEP 1.10

Adjusting Up and Down Tilt

1. Compress the handle and move the arm up/down to adjust the tilt angle of the umbrella.
2. Release the handle to lock it in your desired position.




STEP 1.11

The Left and Right Tilt Function

Pull the swing handle down and simultaneously pull the canopy down with your hands. Adjust to the appropriate fixed position and release the swing handle to lock it in your desired position.


NOTE: The left and right tilt function is limited to two gears on the left and right sides.



STEP 1.12



Closing Umbrella

Turn the (G) Hand Crank counterclockwise to close the umbrella.



STEP 1.13

1. Close the umbrella. Compress the handle and move the arm all the way down.
2. Tie the umbrella to the umbrella pole with the belt when not in use as shown below.




01:

Attach the crank (G) to the handle as shown in figure (1).

Attach the crank (G) by aligning the tap with the hole on the crank (G) until it snaps into place.

To detach the crank, the small part (Not provided by the manufacturer) is required to press the tap to take the crank (G) out.




02:

Attach the crank (G) without using the tap as shown in figure (2).

To detach the crank (G), just take the crank out.

NOTE: Both methods of attaching the crank (G) are acceptable.



Usage Tips

- Umbrella base weights are not included. Do not use this umbrella without umbrella base weights.
- Place umbrella on a stable and level surface.
- Umbrella is suitable for rain showers and light wind.
- Do not use umbrella in inclement weather, such as snow, heavy rain, thunderstorms, or strong wind.
- Close the canopy when umbrella is not in use.

Care and Cleaning

- For best results, clean the frame and fabric with a damp cloth, and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, harsh detergents, or corrosive liquids like gasoline or acetone.
- Store the umbrella in a dry, sheltered place when not in use.
- Tie the canopy closed on windy days to prevent damage to the umbrella.
- Keep the umbrella away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.
- Wipe clean with mild detergent, warm water, and a soft cloth.