

ASSEMBLY INSTRUCTION

Read this instruction carefully. Remove all wrapping material, staples and straps from the carton. See hardware and furniture part list

For guidance. Be sure you have all wooden furniture parts on a clean and flat soft surface, such as a carpet or rug, to prevent from being scratched. Follow the figure to start assembling.

CAUTION :

1. Do not FULLY - TIGHTEN the nut or screw untill all is ready to assemble.
2. Do not OVER - TIGHTEN the nut or screw to avoid causing damages to the thread.
3. Keep all hardware part out reach of children.


PART LIST

No.	DESCRIPTION	QTY
A	CHAIR TOP	1 PC
B	TABLE LEG	4 PCS


HARDWARE LIST

No.	DESCRIPTION	QTY
1	FLAT WASHER 6/19" 	8 PCS
2	SPRING WASHER 6/13" 	8 PCS
3	JCBC SCREW M6 X 70MM 	8 PCS
4	M4 ALLEN KEY 	1 PC

STEP 1



STEP 2



COMPLETED TABLE ASSEMBLY