

Assembly Instructions

DYNAMIC ILLUMINATIONS LAMP POST

ITEM# HO76-NT20005-1



PARTS LISTING EACH DYNAMIC ILLUMINATIONS LAMP POST Contains:

- (1) DYNAMIC ILLUMINATIONS LAMP POST
- (1) POWER CORD with DRIVER
- (6) CONCRETE ANCHORS
- (1) REMOTE

TOOLS REQUIRED FOR INSTALLATION NOT INCLUDED:

- (1) PERCUSSION DRILL
- (1) WRENCH



REMOTE



CONCRETE ANCHORS



POWER CORD W/ DRIVER

USE:

This tree is self-supporting for temporary installation and also comes with concrete anchors to attach it to patios or concrete pads for permanent displays.


Once Assembled and in the desired location, review the instructions for the RGB remote (included in the remote's bag) to change the trees color and light functions.

STORAGE:

Remove nuts from concrete anchors to detach lamp post from the cement. Place lamp post in a cool, dry place.

ASSEMBLY:

1. Carefully remove all items from boxes and remove any packing materials. It is best to assemble this item in the location you intend to display it. ITEM IS RATED FOR INDOOR/OUTDOOR USE.



2. Connect the male Coaxial plug on the base of the lamp post to the female coaxial plug on the driver and power cord. Make sure connection is secure.
3. Plug the Lamp post into a UL approved extension cord or outlet.

NOTE: If you are using concrete anchors to attach this item for permanent installations, please see page 2 for more detailed instruction.


CARE INSTRUCTIONS:

To maintain this item's pristine condition, wipe product with a clean, soft, dry towel and store in a cool, dry place.

Assembly Instructions

**DYNAMIC ILLUMINATIONS
LAMP POST**



ITEM# HO76-NT20005-1



Step 1:
Place the lamp at the installation position and drill 6 corresponding holes according to the installation hole position of the lamp base

Step 2:
Fix the expansion screw on the ground with a wrench

Step 3:
Place the lamp post over the screws so that the corresponding holes in the lamp base fit over the screws.



Step 4:
Use the wrench to fix the nuts onto the screw heads, securing the lamp to its permanent position.

Step 5:
Make sure lamp post is secure, It may be necessary to go back to tighten the nuts to make sure that the lamp is properly secure.