


UMBRELLA



INSTRUCTION BOOK



ATTENTION	02
COMPONENT LIST	04-06
BASE INSTALLATION	07-17
UMBRELLA FRAME INSTALLTION	18-23
UMBRELLA USE & STORAGE	24-28



ATTENTION!

Thank you for purchasing this product. We've created these easy-to-follow instructions to ensure you spend your time enjoying the product instead of putting it together. But, if you need more information than what is provided here, please visit lausaint.com, and refer to the Guides & Documents tab on the product's page.

If you have any questions or problems, please contact us

PREPARATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

PREPARATION

The product is packed in one box to ship.

Before assembly, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 40 minutes



WARNING!

- Tighten each bolt firmly and properly. Do not completely tighten the screws until all screws are started.
- Some parts may contain sharp edges. Wear protective gloves as necessary.
- Children under the age of 16 should not be engaged in the assembly, removal or disassembly of the product.
- Children under the age of 10 should be supervised by a competent adult while using this furniture.
- Please keep children out of the assembly area during assembly.
- This set is heavy, and may require two adults for safe assembly.
- Never use this product as support. Do not shake, lean, or climb on the product at any time.

CARE AND MAINTENANCE

- Before using, clean the product completely with a soft, dry towel.
- When not in use, wipe away dirt or loose objects, wash with a mild solution of soap and water, rinse and dry completely.
- Do not use strong detergents or abrasive cleaners.
- Store the product in a cool, dry location away from sunlight.

CAUTION

- Retain these instructions for future reference.
- Paint on this product might peel off if it is hit or used improperly.
- Use and carry this item with care and apply touch-up paint (not included) when necessary.
- This outdoor furniture is designed and made for personal non-commercial use.
- This item should not be used as a toy or a tool.
- Do not locate the product near any heat source.

WARRANTY















This warranty is extended to the original purchaser and applies to defects in materials and workmanship of your patio furniture provided your furniture is maintained with care and used only for personal, residential purposes.

The frame is warranted to be free from defects in material or workmanship for one (1) year.

The fabric is insured for one (1) year against defects in material or workmanship.







COMPONENT LIST

PARTS #	QTY	DESCRIPTION	PARTS #	QTY	DESCRIPTION
A	1		J	2	
B	1		K	2	
C	1		L	2	
D	1		M	1	
E	1		N	1	
F	1		S	1	
G	4		P	1	
H	2		Q	1	
R	2				



HARDWARE LIST

PARTS #	QTY	DESCRIPTION	
AA	4		M10 X 25mm
BB	4		M10 X 20mm
CC	8		Ø 10
DD	2		M6 X 10mm
EE	3		Ø 8.8 X M6 X 66mm
FF	3		M6 X 15mm
LL	2		M6 X 25mm
GG	1		S8
HH	1		S5
NN	2		S4
JJ	1		S13




PART	QTY	DESCRIPTION	PART	QTY	DESCRIPTION
A	1	Lower Tile	J	2	Support Tube Rim
B	1	Upper Tile	K	2	Sandbag
C	1	Cylinder	L	2	Lower Base Cover
D	1	360° Turntable	M	1	Upper Base Cover
E	1	Pedal	N	1	Middle Tube
F	1	Foot Plate Support Arm	S	1	Rubber Ring
G	4	Plastic Angle Plate	P	1	Umbrella Stand
H	2	Perforated Side Cover	Q	1	Crank
R	2	Non Hole Side Cover			


BASE INSTALLATION

STEP


01




A x1



B x1




Attach the upper tile (B) onto
the lower tile (A).



STEP

02

BASE INSTALLATION



D x1



M6 X 10mm

DD x1




F x1




S5

HH x1



Rotate the 360° rotating unit (D)
to a 45° to adjust the angle.



BASE INSTALLATION

STEP




03

M10 X 25mm **AA** x4

CC x8

M10 X 20mm **BB** x4


S8 **GG** x1




STEP

04

BASE INSTALLATION



Rotate the 360° rotating unit (D) to a 45° to adjust the angle.




BASE INSTALLATION

STEP


05



G x4




Insert corner connector (G) into the four ends of assembled brackets.




STEP

06

BASE INSTALLATION




H x2





R x2

Slide side panel (R) downward between corner connector (G) to the other 2 sides.



H panel is the one with 4 lock-system.
2 H lock panels must be put oppositely.
2 H lock panels must be the parallel to the direction to the foot pedal.



BASE INSTALLATION



STEP

07



J x2


Slide the assembled support tube rim (J) down the base tube (C) and the connect it to the two brackets (A & B).




STEP

08

BASE INSTALLATION







K x2



Place the sandbag (K) into the umbrella base as the picture shows first.


Pull to open the hook and loop pouch on the sandbag (K) and fill with sand at least 220lbs.



BASE INSTALLATION

STEP

09




L x2



JJ x1

1. Ensure the locking mechanism on the lower base cover (L) is in the OPEN position by using the wrench (JJ).
2. Ensure the locking mechanism on the lock panel (H) is in the OPEN position by using the wrench (JJ).
3. Attach the lower base cover (L) to the side panels (R).
4. Close the lower base cover (L) and ensure they are fully closed.



STEP


10

BASE INSTALLATION



JJ x1

Lock the lower base cover (L) and the lock panel (H) by turning the locking mechanisms to the CLOSE position using the the wrench (JJ) as shown.



BASE INSTALLATION

STEP

11



E x1




M x1




M6 X 10mm




DD x1



① Place the upper base cover (M) onto the foot plate support arm (F).




② Insert the foot pedal (E) into the foot plate support arm (F) securing by inserting M6x10 mm bolt (DD) and tighten with the hex wrench S5 (HH).




STEP

12





UMBRELLA FRAME INSTALLTION



P x1



Insert inner tube into outer tube for the umbrella (P).




UMBRELLA FRAME INSTALLTION


STEP

13


- ① Loosen the knob on the handle by turning it counter clockwise.



- ② Insert main tube into the umbrella handle (P).



- ③ Tighten the knob on the handle by turning it clockwise.



STEP

14


UMBRELLA FRAME INSTALLTION



N x1



S x1



UMBRELLA FRAME INSTALLTION

STEP

15

ø 8.8 X M6 X 66mm

EE x1



M6 X 15mm

FF x1




S4

NN x2




M6 X 25mm


LL x2



- ① Insert M6x66 mm bolt (EE) and M6x15 mm bolt (FF) into the middle tube (N), tighten using hex wrench S4 (NN).



- ② Insert M6x25 mm bolt (LL) into the middle tube (N), tighten using hex wrench S4 (NN).



STEP

16

UMBRELLA FRAME INSTALLTION

Ø 8.8 X M6 X 66mm

EE x2






M6 X 15mm

FF x2

S4


NN x2



UMBRELLA FRAME INSTALLTION





STEP

17



Q x1


1. Attach the crank (Q) to the handle as shown. Please refer to last page for details.
2. Shake the canopy to separate the umbrella ribs.
3. Loosen the knob on the handle by turning it counter clockwise.




STEP

18



UMBRELLA USE & STORAGE



1. Slowly turn the crank (Q) clock-wise to open the umbrella, loosen the knob on the handle by turning it counter clockwise.
2. Slide umbrella handle upward until the pole is fully extended and stops.
3. Securely tighten the knob on the handle clockwise to lock into position.



⚠ Sliding the slider to the position that you need and then pin it.




UMBRELLA USE & STORAGE

STEP

19

Step on the foot pedal (E) to allow 360° rotation of umbrella.
Release the foot pedal(E) when the desired position is reached.







STEP

20

UMBRELLA USE & STORAGE

When not in use, or in bad weather, close the umbrella with crank.




Attach the umbrella shade with the pole using the fabric tie.



ATTACHING THE CRANK

1. Attach the crank (Q) to the handle as shown in Figure 1.
2. Attach the crank(Q) by aligning the tap with the hole on the crank(Q) until it snaps into place.
3. To detach the crank, the hex wrench S4 (NN) is required to press the tap to take the crank (Q) out.



DETACHING THE CRANK

1. Attach the crank (Q) without using the tap as shown in Figure 2.
2. To detach the crank (Q), just take the crank out.

