



Dinning Chair

ASSEMBLY INSTRUCTIONS

Guidelines

Thank you for selecting an Elle Decor Collection piece.

Our primary objective is to provide fast, friendly customer service to all of our customers. We are here to help if you have any questions, comments, or are in need of warranty replacement parts.

Please call us toll free at: 1-855-372-2315 U.S.
0-800-051-6775 U.K.

U.S. Monday - Friday 6:00am - 5:00pm PST
U.K. Monday - Friday 2:00pm - 1:00am GMT

Or visit our website:
www.trueinnovations.com

FAILURE TO FOLLOW THESE WARNINGS WHEN IN USE COULD RESULT IN INJURY

- Do not stand on the item or use as a step ladder.
- Do not use this item unless all bolts and screws are firmly secured and fastened.
- Check all bolts and screws every 90 days. Tighten as necessary if any are loose.
- Lift up then move. Pushing over or dragging this product can result in an injury or cause damage to the floor and piece.

Pre-Assembly Preparation:


Please read through this instruction booklet before beginning assembly of this item.

Two adults are recommended for assembly.


- Clear space for assembly and lay out all parts on Parts List. Extra room will allow you to easily determine if all the pieces are present.
- Save all packing materials until assembly is complete to avoid accidentally discarding smaller parts or hardware.
- Keep small parts and pieces away from children and pets until fully assembled.
- Please check for any loose screws and tighten them before use.

WARNING: DO NOT LET CHILDREN PLAY IN OR AROUND THE UNIT DURING ASSEMBLY DUE TO THE POSSIBLE RISK OF INJURY.


Parts List




① Seat (1)



② Left Leg (1)



③ Right Leg (1)



④ Back (1)

Parts List



- A** Cam Bolt
M8x55MM (4)



- B** Cam Nuts
D15x22MM (4)



- C** Cam Nut Bolt
M10x14MM (4)



- D** Dowels
M8x30MM (4)



- E** Allen Key
5MM (1)



- F** Bolts
M6x40MM (2)



- G** Bolts
M6x30MM (2)



- H** Flat Washers
ø 7/12MM (4)





- I** Spring Washers
ø 7/10MM (4)




- J** Allen Key
4MM (1)



- Step 1--**
1. Ensure all parts have been removed from the carton and place on a protected surface or carpet. Check all parts and hardware are the same as the “Parts List”.
 2. Insert wood Dowel (D) into Leg (2) & (3).
 3. Attach Cam Bolt (A) to Legs (2) & (3) by hand clockwise to tighten it.
Note: the hole on the cam Bolt (A) must face up which to be fixed by Cam Nut Bolt (C).
 4. Insert Cam Nut (B) to the rail under seat (1).
Note: the hole on the Cam Nut (B) needs to face the end of rail, which is to be inserted by Cam Bolt (A).



- Step 2--** 1. Attach Legs (2) & (3) with dowel & Cam Bolt to Seat (1). Insert Cam Bolt (A) & Dowel (D) into the rail under the Seat (1) and set with Cam Nut Bolt (C). Then, tighten with Allen Key (E) as shown below.
2. Please do not fully tighten Bolt (C) until the chair is fully assembled.





- Step 3--** 1. Place the Chair upright, attach Back (4) to Legs (2) & (3) with Bolts (G) M6x30MM, Spring Washer (I) and Flat Washer (H). Then, tighten with Allen key (J).
2. Please do not fully tighten Bolt (G) until the chair is fully assembled.



Approx 80% tight


Step 4-- 1. Fix Back to Legs (2) and (3) as below image with Bolts (F) /M6x40MM, Spring Washer (I) and Flat Washer (H) then tighten with Allen Key (J).

2. Please do not fully tighten Bolt (F) until the chair is fully assembled.




Approx 80% tight

Step 5-- 1. Place the chair onto a flat level surface (like a table) and level the seat frame, once the chair is level, tighten all Bolts with Allen Key (E) & (J) fully tighten.



Periodically (every 90 days) make sure that the screws are still fully tightened.
ATTENTION: Be certain that all screws are fully tightened before using chair



Product Dimension

Limited Warranty

The product you have purchased is warrantied against defects in material and workmanship while owned by the “Original Purchaser”. The term “Original Purchaser” is defined as that party or entity which purchases these products from an authorized dealer or retailer as shown by the original sales receipt. This warranty does not apply to “as is” or previously owned products.

The manufacturer warrants its products to be free from defects in materials and workmanship (normal wear and tear, fading and stretching excepted), for one year from the date of purchase, except as provided below under the limited warranty.

This warranty gives you specific rights, and you may also have other rights, which vary from state to state (or country to country). All warranties are limited to the Original Purchaser for normal use by a maximum of two users. Total weight capacity per chair is 250 pounds for a single user.

The exceptions or exclusions to this warranty are:

- Upholstery material and foam cushion material is warranted against defects in material and workmanship for a period of one year, beginning on the date of purchase as shown on the original sales receipt.
- Any warranty claim that is submitted after the limited warranty period, or without proper proof of purchase will not include the cost of parts, labor, or delivery on the warranted parts within a reasonable amount of time. We reserve the right to require damaged parts to be returned to us upon request. Natural markings such as scars, brands, grain variations, wrinkles, color variations, etc. will be considered normal characteristics and not construed as defects.
- For claims or questions concerning this warranty, please contact the Customer Service Department at www.trueinnovations.com. Be prepared to provide your name, address, daytime phone number, the model and purchase order number of the product, date of purchase, and the store where it was purchased. The manufacturer requires that the original sales receipt be submitted with all requests to confirm that you are the Original Purchaser according to our written warranty.