



# ASSEMBLY INSTRUCTIONS

## TOOLS REQUIRED:

Allen wrench ( Provided, part # E )  
Phillips Screwdriver ( not provided )



## BEFORE YOU START:







1. Check the parts against the parts list to make sure all items are present.
2. Assemble your furniture on a soft, flat surface to avoid scratching the finish.
3. **CAUTION:** Do not over tighten screws, nuts or bolts during assembly.
4. Your furniture may require occasional tightening.



## INSTRUCTIONS:

1. Attached the legs frame to the top frame using bolts (A), lock washers(C), flat washers (D), and tighten with wrench (E) as show Figure 1.
2. Attached the bottom shelf to the legs frame using bolts(B), lock washers (C), flat washers (D) and tighten with wrench (E) as show Figure 2.
3. Attached the insert glass (F) to the top frame as show Figure 3.



| No. |   | Hardware List              | Q'ty  |
|-----|---|----------------------------|-------|
| A   |  | Bolt (Ø1/4**1/2")          | 8pcs  |
| B   |  | Bolt (Ø1/4**1-1/4")        | 4pcs  |
| C   |  | Lock Washer (Ø1/4")        | 12pcs |
| D   |  | Flat Washer (Ø1/4" x 16mm) | 12pcs |
| E   |  | Allen Wrench (2**3**Ø4mm)  | 1pc   |
| F   |  | Top Glass                  | 1pc   |

Thank you for purchasing furniture