

ASSEMBLY INSTRUCTIONS

LDFL70TV30FP






2 people for assembly

Please scan this QR code and contact us if you have any questions! If your Climbing Frame has damages, missing parts, problems with installation and use, or you are not 100% satisfied with our products, please scan the QR code and contact us!

Email:vimitty-service@outlook.com

Parts List



Email:vimitty-service@outlook.com











LDFL70TV30FP-A

CODE	DESRIPTION	QTY
1	panel	1
2	base plate	1
3	left side panel	1
4	right side panel	1
5	Left front trim panel	1
6	Right front trim panel	1
9	Left middle side panel	1
10	Right middle side panel	1
11	Upper middle partition panel	2
12	Upper horizontal panel	1
13	Rear stay	1
14	Front tie bar	1
15	Front baffle	1
16	Upper back panel	1
18	Sliding door track	1
19	Rear foot bar	1
20	Front foot bar	1
21	Middle foot bar	2
	Email:vimitty-service@outlook.com	

LDFL70TV30FP-B


CODE	DESRIPTION	QTY
7	Left middle side panel	1
8	Right middle side panel	1
17	Lower back panel	2
22	Left door panel	1
23	Right door panel	1
24	Left drawer front	1
25	Middle drawer front	1
26	Right drawer front	1
27	Slide spacer block	2
28	Left drawer side panel	3
29	Right drawer side panel	3
30	Drawer back panel	3
31	Drawer bottom panel	3
32	Drawer support strip	3
33	Side adjustable shelf	2
	Fireplace Unit	1
	Email:vimitty-service@outlook.com	


Hardware List

A  Ø6 x 33mm 77+3x	B  Ø15x9.5mm 77+3x	C  Ø8 x 30mm 79+3x	D  2x	E  3x
F  5/32"*19mm 8x	G  3x	H  Ø3.5x12mm 36+2x	J  Ø3x12mm 47+2x	K  L=46mm 4X
L  Ø4x35mm 18+2x	M  Ø6/20*15mm 8+1x	N  M5 x 35mm 4x	O  Ø5x40mm 4x	P  M6 x 20mm 7+1x
Q  M6 x 12mm 8+1x	R  Ø10x2mm 4x	S  Ø3.5x12mm 8+1x	T  L=131mm 4x	U  66*31*4mm 4x
V  Ø25mm 77x	AA  Ø4x13mm 2x	BB  L=38mm 2x	CC  L=73mm 2x	DD  Ø4x37mm 2x


Email:vimitty-service@outlook.com


Step 1






Step 2










Email:vimitty-service@outlook.com


Step 3









Step 4






Email:vimitty-service@outlook.com

Step 5





Step 6




Email:vimitty-service@outlook.com


Step 7










Step 8







X2















Email:vimitty-service@outlook.com

Step 9












Email:vimitty-service@outlook.com


Step 10






Step 11







Email:vimitty-service@outlook.com


Step 12



Step 13










Email:vimitty-service@outlook.com


Step 14









Step 15










Email:vimitty-service@outlook.com

Step 16




Step 17







Email:vimitty-service@outlook.com


Step 18






Step 19







Email:vimitty-service@outlook.com


Step 20






Step 21










Email:vimitty-service@outlook.com


Step 22






Step 23










Email:vimitty-service@outlook.com


Step 24









Step 25










Email:vimitty-service@outlook.com


Step 26









Step 27






Email:vimitty-service@outlook.com


Step 28




Email:vimitty-service@outlook.com


Step 29






Step 30







Email:vimitty-service@outlook.com


Step 31







Step 32













Email:vimitty-service@outlook.com


Step 33




















Email:vimitty-service@outlook.com


Step 34






1. When you put the drawer,please note that the drawer wheels on top of the wheels of the slide, then check whether the drawer is smooth when pulled out. Otherwise,the drawer will not be aligned with other drawers.






2. Note: When installing, ensurethat the sub-rail is fully inserted into the main rail



Email:vimitty-service@outlook.com

Step 35



Note: For installation of fireplace accessories,
refer to the separate fireplace manual!!!
Hardware Z is included in the fireplace accessory package.


Set the unit from the back of the fireplace mantel and center it in the opening. Check the alignment and attach the unit to the mantel by inserting screws through the drilled holes on the mantel.

For the exact instruction, please refer to the user's manual provided with the fireplace.

NOTE: Do not attempt to install the unit from the front of the mantel. It will not fit.

Email:vimitty-service@outlook.com

Step 36



⚠ WARNING



Children have died from furnituretipover.

Toreducethe risk of furniture tipover:

- ALWAYS install Anti–tip device provided.
- NEVER exceed the maximum size and weight of the TV shown in the instructions.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!

Email:vimitty-service@outlook.com