



ASSEMBLY INSTRUCTIONS




Notice:


1. Follow the installation instructions. Please confirm all accessories are preset before installation.
2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
3. If you encounter any problems during installation, please contact our customer service.
4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.



Recommended installers:2














Put a carpet on the floor
before unpacking



Estimate installation time:
30minutes







ASSEMBLY INSTRUCTIONS

PART LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
(A)		X1	(G)		X2
(B)		X1	(H)		X2
(C)		X1	(I)		X2
(D)		X1	(J)		X1
(E)		X1	(K)		X1
(F)		X1			

ASSEMBLY INSTRUCTIONS

HARDWARE LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
1	 Ø8*30mm	X16+1	8	 Ø3*15mm	X22+2
2		X12+1	9		X4
3		X12+1	10		X8
4	 Ø4*38mm	X4	11	 Ø1/4"*1-1/4"	X1
5		X4	12		X1
6		X4	13		X1
7	 Ø3*14mm	X48+4	14		X1
			15		X2

ASSEMBLY INSTRUCTIONS




ASSEMBLY INSTRUCTIONS

1





Ⓒ 1PC



Ⓓ 1PC





② 4PCS




ASSEMBLY INSTRUCTIONS

2




ASSEMBLY INSTRUCTIONS


3




Ⓐ 1PC



Ⓔ 1PC





③ 2PCS



① 2PCS




② 6PCS




ASSEMBLY INSTRUCTIONS

4



(A) 1PC




(F) 1PC




Ø4*38mm


(4) 4PCS



(3) 6PCS




(1) 10PCS



ASSEMBLY INSTRUCTIONS

5



(K) 1PC




(10) 8PCS




Ø3*15mm

(8) 22PCS




ASSEMBLY INSTRUCTIONS


6




① 2PC



④ 2PC



⑥ 2PCS




⑤ 2PCS



Ø3*14mm

⑦ 8PCS



ASSEMBLY INSTRUCTIONS

7




Ø3*14mm

⑦ 16PCS




⑨ 2PCS




ASSEMBLY INSTRUCTIONS


8



(G) 2PC



(6) 2PCS




(5) 2PCS



Ø3*14mm

(7) 8PCS



ASSEMBLY INSTRUCTIONS

9




Ø3*14mm

⑦ 16PCS




⑨ 2PCS



ASSEMBLY INSTRUCTIONS

10




①

Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm




②

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm



③

Up-Down Direction Adjustment:


Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm

ASSEMBLY INSTRUCTIONS


11

Common Door Panel Issues:




ASSEMBLY INSTRUCTIONS

12




11 2set

A




2pcs

B




4pcs

C




Ø8*3/4"
2pcs

D



Ø8*1-1/2"
2pcs

E



2pcs

