

Ceiling Fan with Lights




WARNINGS


To reduce the risk of electric shock, make sure electricity has been turned off at the circuit breaker or fuse box before installing.

All wiring must be in accordance with national and local electrical codes. Electrical installation should be performed by a qualified electrician.

The outlet box and ceiling support structure must be securely mounted and capable of supporting the fan.

To reduce the risk of personal injury, do not insert objects between rotating fan blades.





OPERATING INSTRUCTIONS

REMOTE SIGNAL PAIRING

If the remote control loses signal, long press the seconds after the light is powered on. When the light flashes, the pairing is successful.

If the pairing is not successful, turn off the power for one minute and repeat the above operation.

NOTE: Both the fan and the light will be controlled by the remote. The wall switch (if applicable) is not able to control all functions of the fixture.

the fixture.

MEMORY FEATURES

The last color/brightness settings are remembered when it's turned off/on by the remote.

If it's turned off at wall switch, the last color/brightness settings will be remembered only after that setting operated over 10 seconds.

REVERSE DIRECTION

Wait for the fan to stop and reverse blade direction after pressing the Forward or Reverse button.

