




Product Installation Instructions




Product structure decomposition







1x1




2x1




3x1




4x1




5x2




6x2




7x4




8x1




9x5




10x1




11x1




12x1




13x2




14x1



15x1










16x1







1


Accessories list

A		Two In One Screw (6x28mm)	67pcs +3pcs
B		Two In One Nut (10x12mm)	67pcs +3pcs
C		Wood Chipping (6x30mm)	12pcs +2pcs
D		Non-slip pads	10pcs +2pcs
E		1 bis 2 power extension cable	3pcs
F		Fixing clip & screw (3x16mm)	18pcs +2pcs
G		Foot nail	6pcs +2pcs
H		Wire Clamp	4pcs +2pcs
I		Anti fall hardware	2pcs
		AC/DC Adapter (12V $\rightleftharpoons$ 3.0A)	1pcs





Double-head screwdriver, use as required

A		44 pcs	B		37 pcs	C		8 pcs
D		10 pcs						




Use parts ① and ②



Step1




Step2



Step3




Use a screwdriver to lock in the direction of the "+" sign




Disassemble along the direction of "-" sign

Step 1



X4



7


4

Step 2


(B)



x 6




X2



Step 3

(A)




x 4

(B)





x 3



5






Step 4

X2






A x 3

Step 5



A x 5




3


5

6



Step 6




Step 7



Step 8




Step 9





Step 10

(B)




x 2





Step 11



(B)





x 5



Step 12




Step 13





Step 14

Ⓓ




x10




Tear off release paper and stick the black foot pad on the board






Step 15




Step 16







Step 17





Step 18







A		23 pcs	B		30 pcs	C		4 pcs
E		3 pcs	F	 18 pcs	 18 pcs	G		6 pcs
H		4 pcs	I	   	2 pcs			1 pcs




Step 19




Step 20



Step 21



Step 22





Step 23

(B)




x 4





Step 24

(B)





x 4




Step 25

(A)



Step 26

(B)




Step 27


(B)



x 4



Step 28





Step 29

Ⓑ



x 4

16







Step 30

(E)



x 3



x 3

23

Step 31



F



x18



x18





Step 32

Ⓒ




x 6




Use a hammer to drive the nail into the gap of the wooden board and fix the back board

Step 33



H




x 4







Step 34





Install as required




3.5x14mm



Step 35



wall




User's Guide

Thank you for purchasing this product. To use this product, please plug it into a 12V DC power supply. Please use if the product works normally after connecting to power.

Introduction

The box is an intelligent controller with 2 touch buttons. It can turn ON/OFF the light, change light colors, and adjust the light luminance.

Product Show



ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
2. If bubbles appear on the panel, remove the protective film.

Operation



This touch button is used to turn on/off, change colors, and adjust brightness.

A. Short touch -> lighting on -> short touch -> change light color -> short touch -> change light color -> short touch -> lighting off. B. Long touch -> adjust the luminance



This touch button is used to turn on/off the induction function.

A. Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller in 1 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.

B. Long touch to turn off the induction function.

C. Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.