
Four-layer Open Bookcase

Assembly Manual




Please read this manual carefully before any operation and keep it properly for future use.



Step 6:

Finished as below.



▲ WARNING

Keep all parts out of the children's reach.

NOTE

• You need to have a **crosshead screwdriver** beforehand.



- Place all the panels on a clean and smooth surface, such as a rug or carpet, to prevent them from being scratched.
- Make sure that all parts in your product package, including panels and accessories, match up with those listed in the **Panels & Accessories list**.
- Don't tighten screws or bolts until all the pieces are fitted.
- It is recommended to have 2 persons to complete the assembly.

CONTACT US

If you have any issue regarding the product, please contact us at **ecservice@isunon.com.**

NOTE




 $\ensuremath{\mathfrak{D}}$ Handle with care, protective layer is required.

3 In case of any doubts, contact Sunon.

C

Panels





Panel List

Panels	Size	Numbers
1	863*273*18mm	Bottom Board (×1)
2	70*863*18mm	Base Panel (×1)
3 4	1180*294*25mm	Side Boards (×2)
5	915*295*25mm	Top Board (×1)
6 6	1184*435*5mm	Back Boards (×2)
7 7 7	862*272*18mm	Movable Shelf Panels (×3)

Step 5:

Put the Movable Shelf Panels in wherever you want.









Step 4:

Insert **Back Board** along with side slot, and connect them with **Back board slot**.






Accessories List




Assembly Instructions

Step 1:

Fit and fasten the Base Panel on the Bottom Board.







06



Step 2:

Fit and fasten the **Bottom Board** on each of the **Side Panels**.





Step 3:

0

Fit and fasten the **Top Board** on each of Side Panels.

