

# ASSEMBLY INSTRUCTION




Description: DINING CHAIR










## IMPORTANT NOTE :


- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.

### △ PARTS FOR TWO CHAIRS


NO.	PARTS LIST COMPONENT	QTY.
1	CHAIR BACK 	2 PCS
2	SEAT CUSHION 	2 PCS
3	FRONT LEG - R 	4 PCS

NO.	HARDWARE LIST DESCRIPTION	QTY.
A	ALLEN KEY M4 x 60MM 	1 PCS
B	JCBC BOLT M6 x 35MM 	2 PCS
C	JCBC BOLT M6 x 60MM 	8 PCS
D	JCBC BOLT M6 x 80MM 	8 PCS
E	SPRING WASHER M6 x 13MM 	18 PCS
F	FLAT WASHER M6 x 19MM 	18 PCS
G	NAIL ON GLIDE - 15MM 	8 PCS


### STEP 1



### STEP 2



### STEP 3



### STEP 4

