


Instruction



REMARK

We kindly recommend that you check the quantity and condition of the panels and accessories upon receiving the product, as outlined in the instruction manual. If you find any missing parts, damages or encounter assembly issues, please feel free to contact us, and we will be happy to assist you within 24 hours.



IMPORTANT INFORMATION

READ CAREFULLY.

KEEP THIS INFORMATION FOR FURTHER REFERENCE.

GENERAL GUIDELINES

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please **contact us** when further information and help are needed.

NOTES




- Please follow the assembly instructions precisely and only use the product as intended.
- If an odor is present when first opening the package, please leave the unwrapped product in a shaded and ventilated area for a few days to air out.
- Prior to assembly, please check the product for defects or missing accessories. If any defects are found or accessories are missing, do not use product as damage or injury may occur;
Please **contact us** for assistance and replacement.
- It is suggested you regularly check the products bolts and connections to ensure safe use.
- Assemble the item on a soft flat and clean surface to avoid scratches and damage.
- It is recommended that two people assemble this product.

WARNINGS

- During assembly, keep parts and packaging materials away from children and pets as there could cause injury and are a potential choking hazard.
- Avoid sharp objects or corrosive chemicals to prevent damage to the product.
- Please open the item slowly and cautiously to avoid pinching your hands by metal joints, especially children.


ANTI-TIP WARNING

- Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.
- Since different wall materials require different types of fixing device, for advice on suitable fixing systems, contact your local specialized dealer.




- Before installation, please make sure you have all the hardware, the serial numbers are properly labeled corresponding to the list, and the quantity is correct.
- If there are missing accessories or any quality problems or installation problems, please contact our professional customer service first, and we will reply ASAP. Please do not return the product without authorization. If you return it by yourself, you should bear the corresponding labeling fee.
- Enjoy your new purchase!

EXPLODED DRAWING











REMARK


Please do not install the No. 18 and No. 19 boards backward. The No. 18 board is on the left side of the drawer and the No. 19 board is on the right side.






PARTS

 A X81+3	 B X81+3 Ø15	 C X26+2 Ø8X30
 D X6	 E X72+3 Ø3.5X14	 F X36+3 Ø4X35
 CL	 G X16+2 Ø4X14	 H X2+1 Ø6.3X50
 DL	 I X12+1 M4X18	 J X12
 DR	 K X4	 L X20+2
 CR	 M X1	 N X2
	 O X81+3	 P X8+1 Ø4X20

REMARK




MINIFIX POSITION



1


A X8



We kindly recommend that you check the quantity and condition of the panels and accessories upon receiving the product, as outlined in the instruction manual. If you find any missing parts, damages or encounter assembly issues, please feel free to contact us, and we will be happy to assist you within 24 hours.



REMARK

1. Put a blanket under the board to avoid scratch or damage.
2. Please do not screw **A** too deep or too shallow.





2



A X12



3



4




5

	E X18 Ø3.5x14		CL X3		CR X3
---	-------------------------	---	--------------	---	--------------


REMARK

Please do not install the No. 2 and No. 3 boards backward. The No. 2 board is on the left side of the dresser and the No. 3 board is on the right side. Also, please do not reverse the slide rails.







REMARK





When installing, please make sure the screws are flattened, Not crooked; Otherwise the drawers will not be installed perfectly.




6 Right




7 Left




8




9




10





NOTES:
Board No. 9 needs someone's help
Prevent breakage





11




12




13




14





15




16




17





18





19



20





21



22



B × 10




C × 6


23




B × 4





C × 2





24








	G X16 Ø4X14
	K X4
	P X8 Ø4X20

25







	F X36 Ø4X35
---	-----------------------

26





27


	I X12 M4X18
	J X12





28






×2



×2




29



REVERSE

DL


DR



17

x2

DR




23

x2

DL


DR




24

DL




DR




25







30



31




REVERSE



! WARNING

ANTI-TIPPING DEVICE




We have included a set of tipping restraint hardware for this unit. You must install this hardware to prevent accidents or injuries that can result from the unit falling. When properly installed, this restraint can provide protection against the unexpected tipping of the unit due to small tremors, bumps or climbing. We strongly recommend mounting this hardware to a wall stud and your unit.




NOTE: The tipping restraint hardware included is for wooden stud wall construction. It must be attached to a wall stud. Depending upon your wall construction different anchor hardware may be required. Please contact your local hardware store for assistance. Young children can be seriously injured by tipping furniture. You must install the tipping restraint hardware with the unit to prevent the unit from tipping, causing any accidents or damage. The tipping restraints are intended only as a deterrent and are not a substitute for proper adult supervision. The tipping restraints are not earthquake restraints. If you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.


Install the tipping restraint hardware




1. make mark on the wall




2. drill two $\varnothing 6$ holes on the wall



3. put two anchors in the holes



4. fix the device on the wall by the long screws



5. Push the cabinet close to the wall so that the two bases are close to each other, and then put on nylon tie to tighten it

