

800986

CHARTING DESK

ASSEMBLY INSTRUCTION COASTER FINE FURNITURE





www.coastercompany.com

ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

⚠ Warning‼

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.

PARTS IDENTIFICATION:									
A LEFT LEG	1PC	J DRAWER SUPPORT 4PCS							
B RIGHT LEG	4-0	K CONNECTION PIECE 8PCS							
	1PC	L TOP DRAWER 1PC							
C CENTER SUPPORT BAR	1PC	M FRAME DRAWER	;						
D TOP FRAME	1PC	N DRAWER 3PCS							
E FRONT SUPPORT BAR	1PC	O BOTTOM DRAWER 1PC							
F BACK SUPPORT BAR	1PC	P PEN ART TRAY 2PCS							
G PEN HOLDER	1PC	Q ART TRAY 2PCS	,						
H WIRE SUPPORT	2PCS								
I BOTTOM DRAWER SUPPORT	2PCS	R TOP GLASS							

ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.





⚠ Warning‼


- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.

HARDWARE PACKAGE:


Z	DESCRIPTION	FIGURE	Q'TY	Z	DESCRIPTION	FIGURE	
1	TOP GLASS ALLEN-BOLT		4PCS	9	SCREW		4PCS
2	ALLEN BOLT LARGE		9PCS	10	FLOOR LEVELER		2PCS
3	ALLEN BOLT MEDIUM		4PCS	11	ANGLE ADJUSTMENT BACKET		1PC
4	SIDE ALLEN BOLT		4PCS	12	ALLEN KEY		1PC
5	BOLT		14PCS	13	HEXAGONAL KEY	B	1PC
6	CONNECT BOLT		4PCS				
7	ALLEN BOLT SMALL		2PCS				
8	NUT		1PC				











ASSEMBLE INSTRUCTION

- STEP1: Assembly LEFT LEG(A) and RIGHT LEG(B) with FRONT SUPPORT BAR(E) by SIDE ALLEN BOLT(4), with BACK SUPPORT BAR(F) by SIDE ALLEN BOLT(4), with CENTER SUPPORT BAR(C) by ALLEN BOLT-LARGE(2).
- STEP2:SCREW FLOOR LEVELER(10) into the leg.Screw WIRE SUPPORT(H) by ALLEN BOLT-LARGE(2) and NUT(8).
- STEP3:Screw CONNECT PIECE(K) on (C.E.F) by BOLT(5), Screw TOP FRAME(D) on (E) by ALLEN BOLT-SMALL(7).screw ANGLE ADJUSTMENT BACKET(11) on (C) and (D) by BOLT(5).screw PEN HOLDER(G) on (E) by bolt(5).
- STEP4:Screw SUPPORT DRAWER(J)into(E)by CONNECT BOLT(6).

 Then screw BOTTOM DRAWER SUPPORT(I)on(J)by ALLEN BOLT-MEDIUM(3).
- STEP5: Assemble the BOTTOM DRAWER(O) and FRAME DRAWER(M) and TOP DRAWER(L) and DRAWER(N).
- STEP6: Screw the drawer on (J) by SCREW (9).
- STEP7: Place TOP GLASS (R) screw with TOP FRAME (D) by TOP GLASS ALLEN BOLT (1)
- STEP8: Put the PEN ART TRAY(P) and ART TRAY(Q) on the desk.

Page 8 of 8