




























COAT RACK


Assembly Manual






A23  6x 8x30	A22  8x	A04  11x	A17  4x50 28x	A20  3,5x18 8x
F05  4x SYH (J) ASKI	A63  4x 12 cm SYH	A14  1x 86 mm UM	A48  30x AC	A18  20x 3,5x18
A29  3x DP	A16  3x DBL 8mm	A42  3x 5x70	A10  12x 14mm 2. RNK	A06  2x 18 mm 1. RNK
A06  6x 18 mm 2. RNK				A10  16x 14mm 1. RNK






1.RNK	2.RNK
BEYAZ	- ATLANTİK
ATLANTİK	- ANTRASİT
LİDYA	- ANTRASİT
LİDYA	- BUTE BEJ
BEYAZ	- BEYAZ




1




2




3




4




5



6



7



8

