


FRAME TENT

Assembly Instructions


Trademark Innovations



A



B



C



D


A - (4) Frame Poles

B - (3) Fabric Poles

C - (6) Screws


D - (1) Fabric Cover

STEP 1



Attach all four **A** poles to create the two sides of the frame.

STEP 2




Attach the two frames using a **B** pole and two **C** screws. You've now completed the frame.

STEP 3




Insert the remaining 2 **B** poles into the channels at each end of **D**, the fabric cover.

STEP 4



Lay **D** cover with B poles attached over the frame. Connect B poles to bottom of the frame with the remaining 4 **C** screws the same way you did in **step 2**.



Your tent assembly is now complete.

We hope you are satisfied with this product and that it meets your expectations. If there are any parts missing or if there are any other issues with your product, please feel free to contact us at 1-800-906-1639.