





USE AND CARE MANUAL

ARC FLOOR LAMP



Hardware (Parts are not to scale)

H1 Socket ring (Pre-assembled to the socket of socket assembly (B)) 1 pc 	**H2** Pipe assembly (Pre-assembled to the base (F)) 1 pc 	**H3** Flat washer (Pre-assembled to the pipe assembly (H2)) 1 pc 
H4 Spring washer (Pre-assembled to the pipe assembly (H2)) 1 pc 	**H5** Hex nut (Pre-assembled to the pipe assembly (H2)) 1 pc 	**H6** Wrench 1 pc 

THIS MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

IMPORTANT SAFETY INFORMATION

- This lamp is for indoor use only. The lamp should not be used near water. Never immerse the lamp in water or other liquids.
- Never cover the lamp with any object including cloth or paper as this is a fire hazard.
- Do not handle the bulb immediately after the light is turned off as it will be hot.
- This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

PREPARATION


- Before beginning assembly, installation or operation of the product, make sure all parts are present. Compare parts with package contents list and diagram on previous page. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.

ASSEMBLY

1 Assembling the tubes to the socket assembly


- Pull the excess power cord through the tube (E).
- Tightly screw tube (C) onto the arm of the socket assembly (B).
- Tightly screw tube (D) onto the tube (C).
- Tightly screw tube (E) onto the tube (D).

NOTE: Do not twist the power cord.



2 Assembling the pipe assembly to the tube


- Unscrew the hex nut (H5) from the pipe assembly (H2). Remove the pipe assembly (H2) from the base (F), and keep the flat washer (H3), the spring washer (H4), the hex nut (H5) for later use.
- Tightly screw the pipe assembly (H2) onto the tube (E).



ASSEMBLY (continued)


3 Assembling the tube to the base

- Handle the tube assembly in vertical position and then slide the pipe assembly (H2) through the hole on the base (F) as shown. Adjust the socket assembly (B) so that it faces the front of the lamp, then secure with the flat washer (H3), the spring washer (H4) and the hex nut (H5) by the wrench (H6).



4 Assembling the shade

- Unscrew the socket ring (H1) from the socket of the socket assembly (B).
- Place the shade (A) over the socket of the socket assembly (B) and secure with the socket ring (H1).




ASSEMBLY (continued)

5 Installing the light bulb

- Install the light bulb (not provided) into the socket. Use one **MAX 100 W medium base (E26) type "A"** bulb (recommended).
- Plug into the wall outlet, touch the foot switch and enjoy.

NOTE: You can also use one **MAX 16W medium base (E26) self-ballasted LED** bulb. Do not exceed the recommended wattage.



CLEANING

- Do not use any cleaners with chemicals, solvents, or harsh abrasives. Use only a dry, soft cloth to dust or wipe carefully.
- To clean the fixture, pull the plug from the wall outlet. Use a dry or slightly dampened, clean cloth to wipe the exterior surface of the fixture.

TROUBLESHOOTING

- The light does not come on at all:
  a) Ensure the power supply is turned on.
  b) Ensure the cord is plugged into an outlet.
  c) Ensure the circuit breaker is set in the “ON” position.
- Fuse blows or circuit trips when light is turned on.
  a) Check for crossed wires, ensure wiring is correct.

