

Owner Manual

Battery





Warning:

- This lamp is equipped with rechargeable lithium battery.
The battery cannot be exposed to heat source and sunlight.
- Under no circumstances should the lamps be modified or heavily pressed. Any change will lead to safety hidden loyalty.
The manufacturer shall not be responsible for any modified products

Be careful:

- Please read the instructions for use and maintenance of the product carefully;
Use according to the maintenance instructions to ensure the safety of the product, and keep the maintenance instructions properly.
The manufacturer shall not be liable for man-made damage caused by improper use.
Therefore, all kinds of damage caused are not covered by the warranty, and any changed products are not covered by the warranty.
- Never put the product into water or take it with wet hands. -In case of any fault or damage, please stop using immediately and contact the local dealer or qualified technician..
The rated input voltage of the charger is 100 - 240V – 50 / 60Hz, and the rated output current is 5V type-C 1a.
Be sure to use the charger and cable specified.

Care and maintenance:

- If the charging line is damaged,
please select a cable with the same characteristics as the original cable.
When cleaning the lamp,
please do not connect the power supply.
Remember to clean it with a soft cloth, neutral detergent.
- Avoid using alcohol or cleaners containing acetone, sulfur, beryllium, ammonia or any solvent.
- Avoid mechanical pressure and heavy contamination.
Protection grade IP20.
- The replacement service of lamp source can only be provided by the manufacturer.

Operating instructions:

- Touch the top switch lamp of the lamp
(see the schematic icon on the page)
- When the battery has no power, it can be used in indoor environment with protection grade IP20 through USB connection cable..

Place the product on a horizontal solid surface and do not overturn it.

Battery charging:

- Please connect the USB cable to the charging port of the lamp, and connect the other end to the power socket. The red light indicates that it is charging.
 - Please charge continuously for more than 3.5 hours to ensure the best power.
 - We recommend that the battery be fully charged and discharged during the first 10 times of use to ensure the best state of the battery.
- When the power is exhausted, please charge it as soon as possible;
Battery life will be shortened if there is no electricity for a long time.

Battery replacement:

- Please use the original rechargeable battery. In any case, do not use the conventional battery, which may cause danger.
- If you need to replace the battery,
please contact the manufacturer or dealer company.

1. On/Off switch



Touch the top of the lamp

A: Lampshade

B: Tube

C: Base





EN-INFORMATION ON RECYCLING

This product must be disposed of separately from domestic waste. For further information, contact your local authority. If recycling facilities are not available, bring it to the shop where the product was purchased.