









Installation Manual

3D Printer Stand



Customer Service: ahomrt@163.com


Parts List

Number	Parts	Quantity
1		1PC
2		1PC
3		1PC
4		1PC
5		4PCS
6	 	4PCS 4PCS
7		2PCS
8		2PCS
9		2PCS
10		1PC
11		4PCS
12		1PC
13		1PC
14		1PC
15		1PC

Number	Parts	Quantity
A	 M6x35	8PCS
B	 M6x30	32PCS
C	 M6x20	8PCS
D	 M6x12	10PCS
E	 M4x14	2PCS
F	 M4x12	8PCS
G	 M6x20	2PCS
H	 M6	4PCS
I	 M6	2PCS
J		1PC
K		1PC
L	 M4	2PCS
M	  	2PCS
N	 M6x16	8PCS



Step 1

	B x 8
	1 x 1
	2 x 1
	3 x 1
	4 x 1



Step 2

	F x 8
	5 x 4




Step 3





6 x 4

Tips: Both types of No. 6 parts are included.
Please install according to your needs



or



Step 4




B x 6




7 x 2

Note: Part No. 7 needs to be installed with attention to front/back orientation. Please observe the screw hole positions in the diagram.



Step 5

	B x 6
	8 x 2



Step 6



D x 8




C x 8




9 x 2



J x 1




Do not tighten the screw.



Step 7




B x 4




10 x 1

After installing Part No.10, tighten all the screws from the Step 6.





Step 8

	A x 8
	11 x 4




Step 9

	B x 8
	13 x 1
	14 x 1
	N x 8



Step 10




G x 2



H x 2




I x 2



15 x 1



K x 1





Step 11



E x 2




12 x 1



Step 12


Note: Make sure to permanently mount this product on the wall to prevent any potential injuries that may occur if it topples over



H x 2




L x 2




D x 2



M x 2





Final Assembly