
Free-Standing Electric Towel Rack



Instruction Manual


Dear Users:

Thank you for buying our smart electric towel rack. In order to use and insta -ll the product correctly, please read this instruction manual carefully before usi -ng it, keep this manual for reference, and keep the warranty card properly.

Product Parameter:

Product Name: Free-Standing Electric Towel Rack
Product Model: TS06-6080
Rated Voltage: 110V~
Rated Power: 220W
Rated Frequency: 60Hz

Control Schematic



I. Notes

1. The product must be connected to a power supply that matches the rated voltage shown on the rating label. The power cord must be grounded and connected to a circuit protected by an earth leakage circuit breaker (ELCB).
2. Please DO NOT use this product if the heating element or shell is damaged.
3. This product is only used for drying water-washed fabrics, silk fabrics are prohibited.
4. Children, the elderly and those with limited mobility should use this product under the sup -ervision of someone. In order to avoid harm to infants, the power cord socket should be loca ted in a place that is protected fromwater and splash.

II. Product Instructions

1. The main function of this product is to dry and store towels, bath towels and underwear, so as to prevent the skin damage caused by mold, odor and mites due to prolonged drying of towels, ba -th towels and underwear.
2. The towel rack has a grounding function when using. Install it as far away from the shower he -ad as possible.
3. Turn off the power plug when towels and clothes are not dried for along time.
4. Twist the towel and other clothes on the towel rack to dry, please do not put the wet towel dir- ectly on the towel rack.

III. Functional Description

Digital Display Version

Basic functions: switch/timer, drying mode

Switch: Press to start up, each time the machine is started, the previous set working temperature a -nd time are remembered, often press this function key to shut down.

Timing: 2-12 hours can be adjusted by pressing the display every 2 hours from small.


To the large cycle section, such as 2,4,6,8,10,12,--,turn off to--
Set the display to flash three times if no operation is performed in 2 seconds.

Drying mode: three temperature adjustment levels P1, P2 and P3. Each time you press the button, one level is adjusted and the cycle can be adjusted.
The temperature of the shelf corresponds to P1(110-135°F), which varies with the ambient tempe -rature, and P2(125-160°F), which varies with the ambient temperature.

P3(145-170°F), which changes with the ambient temperature.

Set the display for 2 seconds without operation. Flash the displayt hree times to execute the setting.

Standby state: the key indicator light is on, other lights are off, the display shows--Working status: All indicators are lit. The display switches to show the drying mode and the countdown. The main display shows the mode.The mode displays the countdown every 10 seconds and the countdown shows 2 seconds.



IV. Maintenance

1. To better maintain this product, please wipe it with warm water and soft towel(or sponge). Corrosive agent or bleach will damage the product.
2. When maintaining or repairing the machine, please first turn off the power or unplug to en -sure safety.
3. Please DO NOT hit the shell, this product is only for indoor installation and use.
4. If the power cord is damaged, please contact the manufacturer or qualified electric mainte- nance personnel to replace it directly to avoid danger.

V. AFTER-SALE SERVICES

1. The whole machine of our products is guaranteed for one year. During the warranty period , if the product is defective (not natural disaster or man-made damage), the product is repaira -ble. The product can be sent back to the original factory for repair, and if the product cannot be repaired, the faulty product can be replaced free of charge.
2. If the product has failed after the warranty period, the company will provide maintenance service if there are spare parts, and a certain part fee and maintenance fee will be charged.
3. The Company reserves the final right of interpretation of said information.

Warranty Card

Related Information (user fills in `	
Customer Name	Mobile Phone Number
Postal Address	
Product Model	Product Code
Supplier Name	Date of Purchase
Maintenance Location	Invoice Number

Maintenance Record	
Repair Date	
Failure Content	
Processing Details	
Name of Maintenance Unit	Maintenance Unit Phone Number
Maintenance Worker Signature	


Please fill in this warranty card immediately when you purchase our products.

Please keep the warranty card properly.

Consumers do not need to send it back to our company. Please bring the original warranty card and valid invoice when repairing.

Product Installation Instructions

List of Accessories:



Main Frame*1



Floor Stands*2



M5 Machine Wire*4

Installation:

Align the two floor stands with the installation hole on the host and fasten them with screws.

